

# **Telstra Commander@ E105/208+ Installation and Maintenance Manual**

---

**DOC - E+ - IM 546/261  
(ISSUE 1)**



**COPYRIGHT 1995 Telstra Technologies Pty Ltd**

Telstra Technologies Pty Ltd, is a Standards Australia Quality Endorsed Company. This work is copyright. All rights reserved. Other than for purposes and subject to conditions prescribed under the Copyright Act, no part of it may in any form or by any means (electric, mechanical, microcopying, photocopying, recording or otherwise) be reproduced, stored in a retrieval system or transmitted without prior permission from Telstra Technologies Pty Ltd.

All enquiries should be addressed to:

Telstra Technologies Pty Ltd  
A.C.N.006841 345  
Locked Bag 10  
HAWTHORN VIC 3 122  
AUSTRALIA

® Registered Trade Mark of Telstra Corporation Limited A.C.N. 05 1775 556

## Table of Contents

### Chapter One - Introduction to the Commander E105/208+ System

Introduction .....	1-1
General Description .....	1-1
Keystations .....	1-1
Power and Termination Unit .....	1-2
Power-fail .....	1-3
Door Station .....	1-3
System Features .....	1-5
Keystations .....	1-5
Visual Indications .....	1-5
Programmable Facilities .....	1-5
System Facilities .....	1-6
Incoming Calls .....	1-6
During a Call .....	1-6
outgoing Calls .....	1-7
Internal Calls .....	1-8
Equipment .....	1-9
Miscellaneous .....	1-9

### Chapter Two - Power and Termination Unit

Introduction .....	2-1
General Description .....	2-1
Power and Terminating Board .....	2-2
Optional Facilities Board (Optional) .....	2-2
Circuit Blocks - Power and Terminating Board .....	2-3
Transformer .....	2-3
Power Supply .....	2-3
Electronic Choke .....	2-3
Power-fail .....	2-3
Exchange Line Protection .....	2-3
System Bus .....	2-3
Circuit Blocks - Optional Facilities Board.. .....	2-5
Microcomputer Unit (MCU) .....	2-5
Data Transmit and Receive .....	2-5
Door Station Interface .....	2-5
External Music Source Interface .....	2-5

## Chapter Three - Keystations

Introduction .....	3-1
General Description .....	3-1
Keystation Main Board .....	3-2
Hold and Ring Detect Board .....	3-2
Keypad Assembly .....	3-2
Circuit Blocks .....	3-3
Microcomputer Unit Circuit (MCU Circuit) .....	3-3
Power Supply .....	3-3
Isolation Transformer .....	3-3
Data Transmit and Receive .....	3-4
Speech Circuit .....	3-4
Tone Generator .....	3-4
Audio Selector .....	3-4
Audio Amplifier .....	3-4
Line Access Circuit .....	3-4
HRDB-E Board (In Master Keystation) .....	3-4

## Chapter Four - Hardware Installation

Introduction .....	4-1
Component Safety Precautions .....	4-1
Installation Checklist .....	4-2
Installation Procedures .....	4-3
Sales Form Completion/Equipment Ordering .....	4-3
Locate and Mount Equipment .....	4-3
Optional Facilities Board Installation (OFB-E) .....	4-11
Connect and Terminate Cables .....	4-12
Power-Fail Telephone .....	4-17
Protective Earth .....	4-17
General Procedure .....	4-18
Power Up .....	4-18
Check Cabling .....	4-18
Power Down .....	4-18
Plug in Keystations .....	4-18
Keystation Self Test .....	4-18
Test Mode Entry .....	4-18
LED Tests .....	4-19
Programming .....	4-20
Defective Equipment .....	4-20

## Chapter Five - System Programming

Introduction .....	5-1
General Description .....	5-1
Programming Hardware Locations .....	5-1
DIP Switches .....	5-1
General Programming Procedure .....	5-3
Keystation Intercom Address .....	5-3
Master Page-In .....	5-4
Keystation Access Class .....	5-4
Ring Line 1 .....	5-6
Ring Line 2 .....	5-6
Dial Type .....	5-7
Auto Pause Insert .....	5-7
Music-On-Hold .....	5-8
Background Music .....	5-9
Initialise and Reset .....	5-10
Access Class Restriction .....	5-10
Exchange Line Auto Answer .....	5-11
Headset Mode .....	5-12
Programming summary .....	5-13
Software Programming Records .....	5-13

## Chapter Six - Functional Tests and Maintenance

Introduction .....	6-1
General Description .....	6-1
System Tests and Repair Actions .....	6-2
Key station Installation .....	6-2
* Exchange Line Seizure .....	6-3
* Incoming Exchange Call .....	6-3
Off-Hook Signalling .....	6-3
Volume Control .....	6-3
Answering Exchange Call .....	6-3
Automatic Answering Exchange Call .....	6-4
* Outgoing Exchange Call .....	6-4
Decadic to Tone Signalling .....	6-4
Hold .....	6-4
Music-On-Hold .....	6-4
Hold Automatic Ring Back .....	6-4
* Last Number Redial .....	6-4
Abbreviated and Speed Dialling .....	6-5

System Memory Back-Up .....	6-S
* PABX Recall .....	6-5
* Paging .....	6-5
Do Not Disturb .....	6-5
Intercom Signal or Voice Call .....	6-S
Intercom Answering .....	6-5
On-Hook Dialling .....	6-5
* Exchange Line Conference .....	6-6
* Background Music .....	6-6
* Door Station .....	6-6
* Power-fail Telephone .....	6-6
Centel Features .....	6-6
Maintenance .....	6-7
Test Equipment .....	6-7
Voltage Test Points .....	6-7
General .....	6-8
Fault Finding Tables .....	6-8
Repair Procedures .....	6-15
Printed Board Assemblies (PBA's) .....	6-15

## Appendix A - System Characteristics

System Capacities and Limits .....	A-1
System Specifications .....	A-2
Electrical .....	A-2
Environmental .....	A-2
External Music- On-Hold .....	A-2
Dialling .....	A-2
Dimensions and Weight .....	A-2

## Appendix B - Parts Serial Item and Code list

Central Equipment .....	B-1
Keystations .....	B-1
Miscellaneous Items .....	B-1
Maintenance Parts .....	B-2
Documents .....	B-2

## Appendix C - System User Guide

## Table of Illustrations

IL01 - System Block Diagram .....	1-4
IL02 - PTU .....	2-1
IL03 - PTB-E Circuit Block Diagram .....	2-4
IL04 - OFB-E Circuit Block Diagram .....	2-6
IL05 - E105+ and E208+ Keystation .....	3-2
IL06 - Keystation Circuit Block Diagram .....	3-5
IL07 - System Order Form.. .....	4-4
IL08 - Limitations To Wall Mounting .....	4-5
IL09 - Plug-Pack Dimensions .....	4-6
IL10 - Power And Termination Unit Dimensions .....	4-7
IL11 - Power and Termination Unit Mounting .....	4-7
IL12 - Sale/Rental Identifying Window .....	4-8
IL13 - Installing The Handset Rest .....	4-9
IL14 - Keystation Wall Mounting Dimensions .....	4-10
IL15 - Wall Mounting the Keystation .....	4-10
IL16 - Wall Mounting Dimensions For Door Stations .....	4-11
IL17 - Commander E105/208+ Cabling Scheme .....	4-12
IL18 - Bus Length .....	4-13
IL19 - Example Of Allowable Keystation Distances .....	4-13
IL20 - Example Of Unacceptable Cabling Scheme .....	4-14
IL21 - Power and Termination Unit Terminations .....	4-14
IL22 - Modular Socket (KRONE Type) .....	4-16
IL23 - Keystation DIP Switches (In Default Settings) .....	5-2
IL24 - No Master Page-In .....	5-4
IL25 - Program - Local Calls Only .....	5-6

IL26 - Program - Ring On Line 1 .....	5-6
IL27 - Program - No Ring On Line 2 .....	5-6
IL28 - Program - DTMF Dialling .....	5-7
IL29 - Program - Auto Pause Insert.. .....	5-7
IL30 - Music-On-Hold Links .....	5-8
IL31 - Program - Internal, External, and No Music-On-Hold .....	5-9
IL32 - External Music-On-Hold Setting on OFB .....	5-9
IL33 - Internal or No Music-On-Hold Setting on OFB .....	5-9

## Table of Tables

Table 1 - Bus Cabling .....	4 - 1
Table 2 - Keystation Bus Cabling Terminations .....	4 - 15
Table 3 - Door Station Terminations .....	4 - 16
Table 4 - Keystation Voltages .....	4 - 18
Table 5 - Self Test Key Sequence and LED Responses .....	4 - 19
Table 6 - DIP Switch 2 Keystation Options.. .....	5 - 2
Table 7 - Keystation Address Settings.. .....	5 - 3
Table 8 - Example of Exception Table .....	5 - 5
Table 9 - Music Source Links .....	5 - 8
Table 10 - Cable Connections .....	6 - 2
Table 11- Power Supply Test Points .....	6 - 7
Table 12 - Power and Termination Unit Test Points .....	6 - 7
Table 13 - Keystation Test Points .....	6 - 7

## Preface

The preface explains the structure of the Commander@ E 105/208+ Installation and Maintenance Manual. It describes both the overall layout and the layout of each chapter. It also defines and illustrates the conventions used throughout the manual

---

### Purpose of the Manual

---

The purpose of the Commander E 105/208+ Manual is to provide you, as Telstra Technical Staff, with a complete set of clear and concise installation and maintenance procedures. It should be used when installing a Commander E 105+ or E208+ system to ensure the process is completed correctly, safely and easily. It should also be used for maintaining the system when problems arise.

---

#### Audience

---

This manual is written solely for Telstra Technical Staff responsible for the installation and maintenance of the Commander E105/208+ system.

---

### Organisation of the Manual

---

The Commander E105/208+ Installation and Maintenance Manual is divided into nine sections, six chapters and three appendices.

---

#### Chapter One Introduction to the Commander **E105/208+** System

---

This chapter introduces the Commander E105/208+ system and explains the difference between the E105+ and E208+ models. It also provides two descriptive lists: System Features and System Facilities.

---

#### Chapter Two Power and Termination Unit

---

This chapter introduces the Commander E 105/208+ Power and Termination Unit. It begins with a general description; a more detailed explanation follows.

---

#### Chapter Three Keystations

---

This chapter introduces and describes the Commander E 105/208+ keystations. It begins with a general description of the two types of keystations; a more detailed explanation follows.

---

#### Chapter Four Hardware Installation

---

This chapter describes the procedures for installing the Commander E105/208+ system hardware. It begins with an Installation Checklist. Each point in the checklist is then explained in detail.

---

#### Chapter Five System Programming

---

This chapter contains all the procedures for programming the Commander E 105/208+ system. It begins with a general programming procedure and then explains how to program individual features.

---

**Chapter Six Functional Tests and Maintenance**

---

This chapter explains the tests required to verify that the Commander E105/208+ system has been installed and programmed correctly. It also explains how to maintain the system after a fault has occurred during testing or normal daily operation.

---

**Appendix A System Characteristics**

---

This Appendix provides a list of all Commander E 105/208+ system limits and specifications.

---

**Appendix B Parts Serial Item and Code list**

---

This Appendix contains a list of every Serial Item number. A code description and remarks are provided for each item.

---

**Appendix C System User Guide**

---

This Appendix contains a copy of the Commander E 105/208+ System User Guide.

---

## Manual Conventions

---

The symbols and typographic conventions used throughout this manual are as follows.

· Bullets itemise information and procedures.

**Bold** type indicates chapter, section and sub-section headings—  
for example, '**Manual Conventions**'.

**Bold** type also indicates illustration names—  
for example, 'System Block Diagram'.

Illustration numbers appear below the illustration name—  
for example,

System Block Diagram  
[IL01]

Capital letters within these square brackets [ ] identify keys—  
for example, 'When the [REDIAL] key is pressed.. '.

*Italics* emphasise important words within the text—  
for example, '*Do not* over-tighten the screws.'

**Chapter One**  
**Introduction to the**  
**Commander EI 05/208+ System**

---

# Chapter One

## Introduction to the Commander E105/208+ System

### Table of Contents

Introduction .....	1-1
General Description .....	<b>1-1</b>
Keystations .....	1-1
Program and Data Storage .....	1-1
System Communications .....	1-2
DIP Switches .....	1-2
System Master Keystation .....	1-2
Power and Termination Unit .....	1-2
Dial Pad Programming .....	1-2
Power and Terminating Board (PTB-E) .....	1-3
Optional Facilities Board (OFB-E) .....	1-3
Power Supply .....	1-3
Power-fail .....	1-3
Door Station .....	1-3
<b>System Features .....</b>	<b>1-5</b>
Keystations .....	1-5
Visual Indications .....	1-5
Programmable Facilities .....	1-5
<b>System Facilities .....</b>	<b>1-6</b>
Incoming Calls .....	1-6
Audible Signalling .....	1-6
Do Not Disturb .....	1-6
Exchange Call Automatic Answer .....	1-6
Exchange Call Queuing .....	1-6
Flexible Ring Assignment .....	1-6
During a Call .....	1-6
Call Transfer .....	1-6
Conference .....	1-6
Hold - Common .....	1-6
Hold - Recall .....	1-6
Music-On-Hold .....	1-7
Off-Hook Signalling .....	1-7
PABX Recall .....	1-7

outgoing calls .....	1-7
Access Barring .....	1-7
Automatic Pause Insertion on PABX Lines .....	1-7
Decadic to Tone Signalling .....	1-7
Direct Exchange Line Access .....	1-7
Last Number Redial .....	1-7
Live Key Working .....	1-7
On-Hook Dialling/Monitor .....	1-7
Station Abbreviated Dialling .....	1-8
Station Speed Dialling .....	1-8
Internal Calls .....	1-8
Alternative Point Answering .....	1-8
Direct Keystation Selection .....	1-8
Intercom .....	1-8
Intercom Voice/Ring Signalling .....	1-8
Meet-Me Paging .....	1-8
Paging .....	1-8
Voice Call .....	1-8
Equipment .....	1-9
Door Station .....	1-9
Portability .....	1-9
Powerfail Operation .....	1-9
Power Failure Memory Retention .....	1-9
Keystation Directory .....	1-9
Wall-Mounting Bracket .....	1-9
Miscellaneous .....	1-9
Background Music (Optional) .....	1-9
Call Progress Tones .....	1-9
Confidence Tone .....	1-9
Headset Mode .....	1-10
Secrecy .....	1-10
Visual Indication .....	1-10

# Chapter One

## Introduction to the Commander E105/208+ System

---

### Introduction

---

This chapter provides a general description of the Commander E105/208+ system, including an explanation of its features and facilities.

---

### General Description

---

The Commander E105/208+ is an enhancement of the Commander E105/208 system. It provides the essential features and facilities expected in a Commander Key System, and at the same time offers relatively simple installation and maintenance requirements.

The Commander E105/208+ System features a distributed-intelligence architecture based on a six-wire bus configuration.

This architecture eliminates the need for bulky main equipment: the keystations themselves perform the system control functions. The use of a high-performance CMOS single-chip microcomputer in each keystation achieves this function.

A fully equipped system comprises eight keystations and one Door Station, with a maximum bus length of 500 metres (0.5 mm diameter cable).

Refer to **Illustration 1 - System Block Diagram**.

---

### Keystations

---

A single-chip microcomputer in each keystation controls all operational facilities of the Commander E105/208+ system.

An in-built speaker provides keystation tones.

A RISC microcomputer controls all keypad functions.

### Program and Data Storage

The station microcomputer's program and data are stored in 8K words of ROM and 2K bits of RAM. They control all keystation and data communication functions. During a power failure, a supercapacitor back-up protects abbreviated dialling numbers (stored in RAM). This back-up also allows keystations to be unplugged and moved at will from point to point.

---

<b>System Communications</b>	<p>A carrier-sense, multiple-access communications protocol with frequency-shift keying transmission achieves signalling between keystations on the system bus.</p>
<b>DIP Switches</b>	<p>Several keystation facilities are individually programmable via “DIP” switches located in the base of the keystation’s housing.</p> <p>These include:</p> <ul style="list-style-type: none"><li>· keystation address</li><li>· master page inclusion</li><li>· <b>STD/IDD</b> access</li><li>· exchange line ring assignment</li><li>· pulse or tone dialling</li><li>· auto pause insertion.</li></ul>
<b>System Master Keystation</b>	<p>Every system installation must include a System Master Keystation. It contains the Hold and Ring Detect Board (HRDB-E), which provides all the electronics necessary for:</p> <ul style="list-style-type: none"><li>· exchange line ring detection</li><li>· line holding</li><li>· internal music on hold.</li></ul> <p>From a user’s viewpoint, the operation of a system master keystation is identical to that of a standard keystation.</p>
<hr/> <b>Power and Termination Unit</b> <hr/>	<p>The other major component of the Commander E105/208+ system is the Power and Termination Unit (PTU). This compact unit houses the Power and Terminating Board (PTB-E) and Optional Facilities Board (OFB-E).</p> <p>The PTU and OFB-E for the Commander E 105/208+ are the same as that used on Commander E 105/208.</p>
<b>Dial Pad Programming</b>	<p>Several keystation facilities are individually programmed via the station dial pad. These programming steps are password protected.</p>

**Power and Terminating Board (PTB-E)**

The PTB-E provides output terminals for the bus and input terminals for:

- a maximum of two exchange or PABX lines
- plug-pack power supply
- telecommunications reference conductor (if required)
- power-fail telephone
- external music source.

This board also supplies system power supply regulation and the system power-fail relay, as well as exchange line electrical protection.

**Optional Facilities Board (OFB-E)**

An OFB-E is installed in the PTU to provide any or all of the following facilities:

- Door Station
- external music on hold
- background music

Equipped with the same high performance microcomputer as the keystations, the OFB-E contains the required intelligence for bus communications and control functions for the optional features.

The OFB-E is connected to the PTB-E via a flat cable.

**Power Supply**

Input power is supplied to the PTB-E via a double-insulated, mains-operated, in-line plug-pack.

---

**Powerfail**

---

During a power failure, exchange line calls can still be made and received at a specially provided two-wire telephone that is automatically switched across the first incoming exchange pair.

---


**Door Station**

---

The Door Station is a compact unit incorporating a speaker and microphone. A Door Station provides two-way communications between any unsupervised area and a keystation.

# O.F.B.-E

Optional Facilities Board



**Mounted in the P.T.U**


Provides:

- Door Station Interface
- External Music on Hold
- Background Music

Output 24 VAC

**P.T.U.**

**P.T.B.-E**



P = Protection Network

2-wire telephone



**BUS**



Internal Music on Hold

System Block Diagram [ILOT]

---

## System Features

---

---

### Keystations

---

Four types of stations are associated with the Commander E 105/208+ system:

- E105+ Master Keystation  
*Contains the hold and ring detection circuitry for the E105-t System.*
- E208+ Master Keystation  
*Contains the hold and ring detection circuitry for the E208+ system.*
- E208+ Standard Keystation
- Door Station  
*For use on both E105+ and E208+ systems.*

**NOTE:** Both Commander E 105+ and Commander E208+ Master Keystations have keys provided for 2 exchange lines. The E105+ Master Keystation however differs from the E208+ in that the inbuilt HRDB-E (Hold and Ring Detect Board) is only equipped to handle 1 exchange line.

Standard Keystations are identical for both size systems.

---

### Visual Indications

---

Visual indicators on each keystation show the status of:

- Exchange lines  
*idle            incoming ring*  
*busy            hold*  
*conference*
- Intercom circuit  
*free            busy*  
*incoming cull*
- Do Not Disturb
- Speaker On.

---

### Programmable Facilities

---

Several options and facilities can be programmed at each keystation via “DIP” switch settings. The DIP switches are located under the base of the keystation. A small protective cover must be removed to access the DIP switches. Further options are programmed via the keystation dial pad. These options are password protected.

---

## System Facilities

---

---

### Incoming Calls

---

#### Audible Signalling

Distinctive ring tones from the keystation loudspeaker signal incoming exchange line, intercom and hold recall calls.

NOTE: The exchange line ring cadence is internally generated within the system and **does not** track the exchange ring cadence.

#### Do Not Disturb

When invoked, this facility blocks the audible signals of all incoming exchange line and intercom calls. Each keystation provides visual indication of DND.

#### Exchange Call Automatic Answer

Each keystation can be programmed to automatically answer incoming exchange line calls when the handset is lifted.

#### Exchange Call Queuing

When Exchange Call Automatic Answer is selected, and more than 1 call is ringing, lifting the handset will answer the oldest call.

#### Flexible Ring Assignment

Each keystation can be programmed to signal or not signal incoming exchange line calls by an audible tone on a per-line basis.

---

### During a Call

---

#### Call Transfer

Allows an exchange line call to be transferred to another keystation after it has been announced.

#### Conference

Allows the establishment of a conference with one external and two internal parties or three internal parties.

#### Hold - Common

Places a call on hold for any keystation to retrieve.

#### Hold - Recall

When an exchange line call is placed on hold, a reminder ring signal is activated every 90 seconds at the keystation that initiated the hold condition.

<b>Music-On-Hold</b>	Automatically transmits music to a caller on hold. The music may be generated internally, or provided by an external source. (The Optional Facilities Board is required for externally provided Music-On-Hold).
<b>Off-Hook Signalling</b>	Provides a muted audible exchange line signal to a busy keystation when it receives an incoming exchange line call.
<b>PABX Recall</b>	When the system operates behind a PABX, this facility enables access to the facilities of the host PABX. Only TLB is provided.
<hr/> <b>Outgoing Calls</b> <hr/>	
<b>Access Barring</b>	Restricts the range of numbers that can be dialled on a keystation. Each keystation can be programmed for one of two classes of Access Barring via a DIP switch located in the keystation. Class 1      unrestricted access Class 2      access restricted to exception table entries plus access to 000, 008, 013, 016n > n, 122n > n, 11441 > 11440, 1 3 n > n, 0175, 18nn. Exception Table is 8 entries of 4 digits each.
<b>Automatic Pause Insertion on PABX lines</b>	When using the abbreviated dial and redial facilities on PABX lines, the system automatically inserts a three-second pause.
<b>Decadic to Tone Signalling</b>	After connecting a keystation to a called party on a decadic exchange line, the dial pad can be used to send further numbers in tone (DTMF) signalling.
<b>Direct Exchange line Access</b>	Direct access to exchange lines by any keystation using a single key.
<b>last Number Redial</b>	Press [REDIAL] to automatically redial the last number dialled.
<b>live Key Working</b>	After pressing an exchange line key, the loudspeaker automatically activates to allow the dialling of a number without lifting the handset.
<b>On-Hook Dialling/Monitor</b>	Enables a keystation to originate a call and monitor its progress without lifting the handset. However, you must use the handset to speak to the called party.

<b>Station Abbreviated Dialling</b>	By pressing [MEMORY] and then dialling a memory location (0-9), each keystation can access up to ten programmed numbers having a maximum of 19 digits. Each keystation has its own ten-number memory.
<b>Station Speed Dialling</b>	When the handset is lifted or the station is 'off-hook', and an exchange line is selected, up to 8 speed dial keys can be used to select pre-programmed speed dial numbers. These numbers are a subset of those used for station abbreviated dialling.
<hr/> <b>Internal Calls</b> <hr/>	
<b>Alternative Point Answering</b>	Allows any keystation to answer an intercom call directed to another keystation by pressing [CONF].
<b>Direct Keystation Selection</b>	Allows single-button access to another keystation by pressing the required DSS key (1 to 8).
<b>Intercom</b>	Establishes a private call between any two keystations.
<b>Intercom Voice/Ring Signalling</b>	<p>Allows the keystation user to select to make either an intercom signal call or an intercom voice call. An intercom signal call is when an intercom ring is sent to the called keystation. An intercom voice call is when, after a short tone, the caller can speak directly to the called party through the called station's inbuilt speaker.</p> <p>In both cases, the called party must lift the handset to speak to the calling party.</p>
<b>Meet-Me Paging</b>	After a paging announcement, the paged person can contact the calling party by pressing [PAGE] on any keystation.
<b>Paging</b>	Allows paging of all other keystations through their loudspeakers from any keystation. Individual keystations can be programmed to bar the reception of a page announcement. (Note that keystations programmed not to receive page calls are also excluded from receiving Door Station chimes).
<b>Voice Call</b>	Allows a keystation user to call any keystation and speak directly through the speaker of the called keystation.

---

---

**Equipment**

---

---

**Door Station** Provides two-way communication between an unsupervised area and any keystation on the system. (Note that keystations programmed not to receive paging calls are also excluded from receiving door station chimes.) (The Optional Facilities Board is required to provide the Door Station facility.)

**Portability** Allows movement of keystations to other sockets in the system while still retaining their identity and abbreviated dialling information.

**Powerfail Operation** During a power failure, exchange line calls can be made and received at a specially provided two-wire telephone.

**Power Failure Memory Retention** Retains the keystation's abbreviated dialling memory during an extended power failure for a minimum of 24 hours.

**Keystation Directory** A directory label designed to adhere to the face of each keystation is provided for the recording of extension numbers and abbreviated dial numbers.

**Wall-Mounting Bracket** Enables keys stations to be wall-mounted.

---

---

**Miscellaneous**

---

---

**Background Music (Optional)** Music supplied from an external source can be broadcast through keystation loudspeakers, and turned on and off at each keystation as required. The music automatically turns off when a call is in progress. The Optional Facilities Board and an external music source (including a Telstra approved Line Isolation Unit) are required to provide this facility.

**Call Progress Tones** Tones indicate the call status to the user.

**Confidence Tone** A low-level, audible tone indicates that a key press is registered. The user enables or disables this facility.

**Headset Mode**                      A keystation handset may be replaced by a suitable Austel permitted headset. When connected and activated, the [SPKR] key is used to perform the off-hook function. Headset mode is protected against activation and deactivation by a two-key activation sequence.

**Secrecy**                              All external and internal calls provide secrecy.

**Visual Indication**                Visual display is provided at each keystation to indicate:

- all incoming exchange line calls
- exchange line held condition
- exchange line in-use condition
- exchange line in conference
- other conditions such as intercom line status, Do Not Disturb, Speaker On and Headset Mode selected.

# **Chapter Two**

## **Power and Termination Unit**

---

## **Chapter Two**

### **Power and Termination Unit**

#### **Table of Contents**

Introduction .....	2-1
General Description .....	2-1
Power and Terminating Board .....	2-2
Optional Facilities Board (Optional) .....	2-2
Circuit Blocks . Power and Terminating Board .....	2-3
Transformer .....	2-3
Power Supply .....	2-3
Electronic Choke .....	2-3
Powerfail .....	2-3
Exchange Line Protection .....	2-3
System Bus .....	2-3
Circuit Blocks . Optional Facilities Board .....	2-5
Microcomputer Unit (MCU) .....	2-5
Data Transmit and Receive .....	2-5
Door Station Interface .....	2-5
External Music Source Interface .....	2-5

## Chapter Two Power and Termination Unit

---

### Introduction

---

This chapter provides a general description of the Power and Termination Unit and its two major components: the Power and Terminating Board (PTB-E) and Optional Facilities Board (OFB-E). It also includes PTB-E and OFB-E circuit block diagrams and a description of all circuit blocks depicted in both diagrams.

---

### General Description

---

The Power and Termination Unit (PTU) houses the Power and Terminating Board (PTB-E) and Optional Facilities Board (OFB-E). Refer to **Illustration 2 - PTU**.

The PTU is a wall-mounted plastic housing that contains:

- exchange line terminations
- system bus terminations
- line protection circuitry
- power-fail relay
- system power regulation and reticulation.

An in-line, mains-operated plug-pack, supplied as part of the PTU, supplies the PTU's AC power.



PTU  
[IL02]

---

**Power and Terminating Board**

---

**Board Code - PTB-E****Location - PTU Base****Description -** The PTB-E provides:

- the system terminal strip  
*Used to terminate: incoming exchange lines; the system bus; the power-fail station and external background music inputs.*
- power supply circuitry
- exchange line protection.

---

**Optional Facilities Board (Optional)**

---

**Board Code - OFB-E****Location - PTU Cover****Board Description -** An OFB-E is installed in the PTU when any of the following optional facilities are required:

- Door Station
- external music-on-hold
- background music

The OFB-E uses the same microcomputer as the keystations. It contains: the intelligence required for bus communications, the control features necessary for the optional facilities and the Door Station input terminals. The OFB-E connects to the PTB-E via a flat cable.


---

## Circuit Blocks - Power and Terminating Board

---

Refer to **Illustration 3 - PTB-E Circuit Block Diagram.**

<u>Transformer</u>	A double-insulated plug-pack that delivers 24V AC Nom. to the power supply.
<u>Power Supply</u>	Delivers DC voltages for the system bus communications pair.
<u>Electronic Choke</u>	Decouples the Audio and Frequency Shift Keying signals from the DC feed.
<u>Powerfail</u>	When power fails, a relay releases that switches each exchange line pair in the system to a standard two-wire telephone.
<u>Exchange line Protection</u>	Metal Oxide Varistors (MOV's) isolate exchange line pairs from high voltage surges on the exchange lines.
<u>System Bus</u>	<p>The system bus consists of a pair of wires for each exchange line (the Commander E 105+ system contains one spare pair) and a single pair for the following:</p> <ul style="list-style-type: none"><li>· system communication</li><li>· power reticulation</li><li>· intercom</li><li>· <b>paging</b></li><li>· conference calls.</li></ul>



PTB-E Circuit Block Diagram  
[IL03]

---

## Circuit Blocks - Optional Facilities Board

---

Refer to **Illustration 4 - OFB-E Circuit Block Diagram.**

---

### Microcomputer Unit (MCU)

---

The OFB-E Microcomputer Unit controls:

- Door Station interface
- external music source interface

It works in conjunction with the keystation microcomputer to control the systems' optional facilities.

**NOTE:** PABX Earth Recall is not available on the Commander E105/208+.

---

### Data Transmit and Receive

---

Converts data transmitted on the bus pair into logic levels for the Microcomputer Unit.

---

### Door Station Interface

---


Provides circuitry to connect a single Door Station to the system. Intercom transmission between the door and keystation is via the bus intercommunication channel.

---

### External Music Source Interface

---

Provides circuitry for the connection of an external music source to the system. Background music and music-on-hold are relayed to the keystations via the bus intercommunication channel.



OFB-E Circuit Block Diagram  
[IL04]

# **Chapter Three**

## **Keystations**

---

# Chapter Three

## Keystations

### Table of Contents

Introduction .....	3-1
General Description .....	3-1
Keystation Main Board .....	3-2
Hold and Ring Detect Board .....	3-2
Keypad Assembly .....	3-2
Circuit Blocks .....	3-3
Microcomputer Unit Circuit (MCU Circuit) .....	3-3
Keypad RISC Processor .....	3-3
Memory .....	3-3
Memory Back-Up Circuit .....	3-3
Reset.. .....	3-3
Power Supply .....	3-3
Isolation Transformer .....	3-3
Data Transmit and Receive .....	3-4
Speech Circuit .....	3-4
Tone Generator .....	3-4
Audio Selector .....	3-4
Audio Amplifier .....	3-4
Line Access Circuit .....	3-4
HRDB-E Board (In Master Keystation) .....	3-4
Line-Hold Circuit .....	3-4
Ring Detect Circuit .....	3-4

---

## Introduction

---

This chapter provides a general description of the keystation and its two major printed circuit boards. It then provides descriptions of each keystation circuit block and a circuit block diagram.

---

## General Description

---

There are 3 types of system keystations.

- E105+ Master Keystation  
*Contains the hold and ring detection circuitry for the Commander E105+ system.*
- E208+ Master Station  
*Contains the hold and ring detection circuitry for the Commander E208+ system.*
- E208+ Standard Keystation

**NOTE:** Both Commander E105+ and Commander E208+ Master Keystations have keys provided for 2 exchange lines. The E105+ Master Keystation however differs from the E208+ in that the inbuilt HRDB-E (Hold and Ring Detect Board) and the Control Board are only equipped to handle 1 exchange line.

Standard Keystations are identical for both size systems.

All keystations contain a telephone network that includes:

- a handset
- a dial keypad incorporating a RISC processor.
- non-locking function keys
- status Light Emitting Diodes (LEDs) (housed in keys)
- a speaker
- volume control.

The Master Keystations also carry a line hold and ring detection HRDB-E circuit board.

Refer to **Illustration 5 - E105+ and E208+ Keystation.**

---

**Keystation Main Board**

---


**Board Code** - KSB-E-A (Keystation Main Board)**Location** - Keystation**Board Description** - This board contains a high-performance, single CMOSchip microcomputer and associated circuitry. It controls all keystation, system and data communications functions and contains the:

- keystation power supply
- speech and audio circuitry
- data transmit and receive circuitry
- line control circuitry.

---

**Hold and Ring Detect Board**

---

**Board Code** - HRDB-E**Location** - Master Keystation**Board Description** - This board contains circuitry that controls system ring detection and line holding functions. It also accommodates the internal music-on-hold feature. This board differs between Commander E105+ and Commander E208+ systems.**Keypad Assembly****Location** - Keystation**Description** - This assembly generates dialling and system function signals. It consists of a rubber keypad and printed board assembly connected to the keystation main board via a ribbon connector. The assembly is controlled by a RISC processor. This processor also handles keypad interfacing with the keystation Main Board.

Commander **E105+** and **E208+** Keystation  
[IL05]

---

## Circuit Blocks

---

Refer to **Illustration 6 - Keystation Circuit Block Diagram.**

---

### Microcomputer Unit Circuit (MCU Circuit)

---

Controls keystation operation. The MCU works in conjunction with other keystations (and the OFB-E, if installed) to control the system operation.

Specifically, the keystation central microcomputer controls the:

- exchange line interface
- keystation communications and operation
- intercom keystation interconnection
- connection of signal tones to the keystation
- system option programming.

### Keypad RISC Processor

This process or provides an intelligent interface between the keypad and the station Microcontroller unit. It provides mapping for all 'intelligent keys', such as DSS/Speed Dial keys and Centel® functions keys.

### Memory

Keystation memory consists of 8K words of ROM (10 bits per word) and 5 12 words of RAM (4 bits per word).The microcomputer uses the Random Access Memory (RAM) to store abbreviated dialling codes.

The microcomputer uses Read Only Memory (ROM) to store the keystation's operating program.

### Memory Back-Up Circuit

During brief power down periods, the memory back-up circuit protects the abbreviated numbers stored in RAM. This circuit consists of a supercapacitor (charged ready for use under normal keystation operating conditions) and associated control circuitry.

### Reset

When low voltages are detected, the reset circuit transmits an interrupt signal to the Microcomputer Unit (MCU) and generates a reset pulse when power is restored.

---

### Power Supply

---

A DC-DC converter that steps down and isolates bus voltages to supply the keystation circuit requirements.

---

### Isolation Transformer

---

Isolates keystation circuitry from the bus.

---

**Data Transmit and Receive**

---

Converts data transmitted on the bus power pair into logic levels, then directs the signal to the keystation MCU serial port signalling interface.

---

**Speech Circuit**

---

Provides an interface for the telephone network intercom channel, transmission circuit and handset.

---

**Tone Generator**

---

Provides the DTMF tone and all audible tones emitted by the keystation.

---

**Audio Selector**

---

This circuit couples either:

- audio signals from the speech circuit to the audio amplifier when connected to either the telephone line or the bus,
- or
- audible tones from the tone generator to the audio amplifier when required for either audible tones in the earpiece or transmission of DTMF signals.

---

**Audio Amplifier**

---

Under control of the audio selector, the audio amplifier drives the keystation speaker. Line access connects lines to the speech circuit by an MCU-controlled relay.

---

**line Access Circuit**

---

Provides an interface between the speech circuit and either of the exchange lines. It also provides a solid-state switch for dialling purposes.

---

**HRDB-E Board (In Master Keystation)**

---

The HRDB-E board is contained in the system Master Keystation.

---

**Line-Hold Circuit**

---

Provides line-holding control at the master keystation in the system.


All other keystations in the system can assert line-holding control. They can also transmit and receive the line hold on/off codes (received by the master keystation) along the bus communications channel (service a and service b) .

---

**Ring Detect Circuit**

---

Provides ring detection for the master keystation only. All other keystations in the system respond to “line ringing” and “line terminated” codes transmitted by the master keystation along the bus communications channel.



Keystation Circuit Block Diagram [1L06]

# **Chapter Four**

## **Hardware Installation**

---

## Chapter Four

### Hardware Installation

#### Table of Contents

Introduction .....	4-1
Component Safety Precautions.....	<b>4-1</b>
Installation Checklist .....	4-2
Installation Procedures .....	4-3
Sales Form Completion/ Equipment Ordering .....	4-3
Locate and Mount Equipment .....	4-3
Customer Responsibilities .....	4-3
Power and Termination Unit (PTU) .....	4-5
Power Supply Plug-Pack .....	4-8
Sale/Rental Window.. .....	4-8
Wall Mounting Keystations.. .....	4-9
Door Station .....	4-11
Optional Facilities Board Installation (OFB-E) .....	4-11
Connect and Terminate Cables .....	4-12
Cabling Limitations .....	4-13
Power and Termination Unit (PTU) Terminations .....	4-14
Power Supply Plug- Pack .....	4-14
Exchange Lines .....	4-14
Keystations.. .....	4-15
Modular Socket Termination .....	4-15
Door Station .....	4-16
Power-Fail Telephone .....	4-17
Internal Music-On-Hold.. .....	4-17
External Music Source .....	4-17
Protective Earth .....	4-17
General Procedure .....	<b>4-18</b>
Power Up .....	4-18
Check Cabling .....	4-18
Power Down .....	4-18
Plug in Keystations .....	4-18
Keystation Self Test .....	4-18
Test Mode Entry .....	4-18

LED Tests .....	4-19
Keyboard Tests .....	4-19
Audio Circuit Test .....	4-19
Test Failure .....	4-20
Test Mode Exit .....	4-20
Programming .....	4-20
Defective Equipment .....	4-20

# Chapter Four

## Hardware Installation

---

### Introduction

---

This chapter describes the procedures for installing the Commander E105/208+ system hardware.

It begins with an Installation Checklist that summarises all the hardware installation procedures. Each point in the checklist is then covered in detail, with full installation procedures and additional relevant information. Where appropriate, an illustration and reference are provided.

---

### Component Safety Precautions

---

Commander E105/208+ equipment contains a considerable number of MOS and other static-sensitive components. To reduce the incidence of premature failure due to static discharge, ensure that you take the following precautions.

- *Always* discharge static from yourself before you handle a printed board assembly (PBA)
- *Always* disconnect power before handling or installing PBAs
- Always handle PBAs by the edges
- Never touch PBA tracks or edge connectors. Contaminants introduced by fingers can cause corrosion and high-resistance connections.
- Never touch components. They are physically delicate and finger pressure can fracture (but not necessarily break) components **leads**.
- Never attempt to repair power plug-packs in the field. They are powered from the 240V mains supply and contain hazardous **voltages**.

Bus cabling is polarity-sensitive. It is essential that correct polarity is maintained. Be careful when checking voltages on cabling.

BUS WIRE COLOUR	MODULAR SOCKET	BUS WIRE DESIGNATION
Green	1	L2b
Black	2	Service b (-50V)
Blue	3	L1b
White	4	L1a
Red	5	Service a (0V)
Orange	6	L2a

Table 1 - Bus Cabling

---

## Installation Checklist

---

Use the following checklist in conjunction with the detailed procedures that follow to ensure that you install the Commander E 105/208+ system correctly.

- Order the necessary equipment using the Sales Form
- Locate and mount equipment
  - power and termination unit
  - power supply plug-pack
  - keystations
  - Door Station
  - power-fail telephone
- Connect and terminate cables
  - system bus
  - power supply plug-pack
  - exchange lines
  - keystations
  - modular sockets
  - Door Station
  - power-fail telephone
  - external music-on-hold
- Connect OFB-E and Telstra reference conductor (if required)
- Power up
- Check cabling
- Power down
- Plug in keystations
- Program the system (refer to Chapter Five)
- Power up
- Wait 10 seconds for the system to initialise
- Test the system (refer to Chapter Six)

**IMPORTANT**

- Designate sale or rental keystation
- Complete installation dates and warranty labels on equipment
- Complete site records
- Leave system user guide with system administrator.

---

## Installation Procedures

---

---

### Sales Form Completion/ Equipment Ordering

---

The Telephone Order for any S.B.S. must be accompanied by an S.B.S. System Order. Sales staff, after consultation with the customer, must complete the S.B.S. System Order.

Use the information provided in the System Order form to order the various items required for the installation, and to find the required programming information.

Forward three copies of the System Order to the installation area along with the Telephone Order.

On completion of the installation, any variations to the System Order must be noted on each copy of the order.

Keep one copy of the System Order with the equipment as a record of the particular installation. Return the remaining two copies to the local Telstra Business Office.

Refer to **Illustration 7 - System Order Form.**

---

### locate and Mount Equipment

---

#### Customer Responsibilities

The customer is responsible for providing:

- satisfactory lighting for installation and maintenance activities
- a single-phase, correctly earthed, 220-250V, 10A, 50Hz AC general-purpose power outlet within one metre of the equipment.



### Commander E105/208+ System Order Form

System Order No (Service Plus)

Customer's Name \_\_\_\_\_

Address \_\_\_\_\_

Town or Suburb \_\_\_\_\_ Post Code \_\_\_\_\_

Nature of Business \_\_\_\_\_

Customer Contact \_\_\_\_\_ Telephone \_\_\_\_\_

Sales Contact \_\_\_\_\_ Telephone \_\_\_\_\_

Type of Payment  **Lease**  **Outright Purchase**  
 **Standard Rental**  **Short Term Rental**  
 **Temporary Rental**  **Other**

Division  **Comm**  **C & G**  **Cons**

STD Code \_\_\_\_\_ Service No \_\_\_\_\_ PABX Extn \_\_\_\_\_ If off PABX \_\_\_\_\_

Install Req Date \_\_\_\_\_ App'n Date \_\_\_\_\_ Date Order Issued \_\_\_\_\_ Date Completed \_\_\_\_\_

D D M M Y Y    D D M M Y Y    D D M M Y Y    D D M M Y Y

Equipment	E105+ Equipment					E208+ Equipment				
	PCMS Code	Exp	Technical Code	Serial/Item	Qty	PCMS Code	Exp	Technical Code	Serial/Item	Qty
Business Starter Pack										
Power and Terminating Unit			PTU-E	546/1				PTU-E	546/1	
Optional Facilities Board			OFB-E	546/5				OFB-E	546/5	
Keystation Master			TS-E105P-M	546/209				TS-E208P-M	546/210	
Keystation			TS-E208P-S	546/212				TS-E208P-S	546/210	
Door Station			DS-E	546/13				DS-E	546/13	
Wall Mounting Kit			WMK-E	546/221				WMK-E	546/221	
Powerfail Telephone										
Wall Socket			SMK-(6x6)-CONN	268/125				SMK-(6x6)-CONN	268/125	

**Programmable Options**

SW1 Station Address					SW2							Keyboard Programming
STN	1	2	3	4	1	2	3	4	5	6	7	8
					All Call Page	STD Access	Ring Line 1	Ring Line 2	Dial Type	Auto Pause Insert	Auto Answer	
1	0	0	0	1								
2	0	0	1	0								
3	0	0	1	1								
4	0	1	0	0								
5	0	1	0	1								
6	0	1	1	0								
7	0	1	1	1								
8	1	0	0	0								
Door Sin					1 = Enabled 0 = Disabled (1)	1 = Decadic 0 = DTMF (1)	1 = Enabled 0 = Disabled (0)	1 = Enabled 0 = Disabled (0)				

Switch Positions      If '0' go to Exception Table

**Exception Table**

Location	Station 1	Station 2	Station 3	Station 4	Station 5	Station 6	Station 7	Station 8
	Entry (Maximum 4 digits)							
1	(*)	(*)	(*)	(*)	(*)	(*)	(*)	(*)
2	(*)	(*)	(*)	(*)	(*)	(*)	(*)	(*)
3	(*)	(*)	(*)	(*)	(*)	(*)	(*)	(*)
4	(*)	(*)	(*)	(*)	(*)	(*)	(*)	(*)
5	(*)	(*)	(*)	(*)	(*)	(*)	(*)	(*)
6	(*)	(*)	(*)	(*)	(*)	(*)	(*)	(*)
7	(*)	(*)	(*)	(*)	(*)	(*)	(*)	(*)
8	(*)	(*)	(*)	(*)	(*)	(*)	(*)	(*)

**Exchange Line Connections**

Exchange Line	Tick if Required	Permit No	Service Order No	Serial/Item 546/203 FM-00345-R01 1520
Tie = Non PABX	External Music Source			
= Non PABX				

System Order Form [IL07]

## Power and Termination Unit (PTU)

### Mounting Limitations

Ensure that you install equipment in a position allowing adequate access for maintenance activities. The space requirements for wall-mounted equipment are:


- no less than 300mtn clear wall space on each side
- no less than 380mm and no more than 1.8m from the floor
- no less than one metre of clear floor space in front of the equipment.

Refer to **Illustration 8 - Limitations to Wall Mounting.**

**NOTE:** Initial systems are equipped with a conventional non-in-line plug-pack. You may be unable to plug this type of plug-pack into some power points with limited clearance, such as a 'low-line GPO' on ducted skirting.


Accordingly, locate an appropriate 240V AC GPO to accommodate the plug-pack dimensions. Refer to **Illustration 9 - Plug-Pack Dimensions.**

If such an outlet cannot be located, a short 240V AC extension cord or similar should be used to enable installation.



Plug pack may be located as close to power outlet as required within one metre of the PTU

limitations To Wall Mounting  
[IL08]



Plug-Pack Dimensions  
[IL09]

### Installation Procedure


Mount the PTU as follows:

- Unclip the cover from the base by using a screwdriver in the slot in the top or bottom of the unit
- Disconnect the LED flying lead from the PTB-E
- Attach the base to the wall using three screws. Do not overtighten screws.
- Remove the cable entry tab at the bottom or top of the base by pushing firmly downwards


*You may also bring cables in from the back of the PTU through the centre hole.*

- Pass the cables through the entry
- Place wires in screw terminals and tighten
- Attach LED flying lead to PTB-E
- Replace PTU cover on base.

Refer to **Illustration 10 - Power and Termination Unit Dimensions** and **Illustration 11 - Power and Termination Unit Mounting**.



Power and Termination Unit Dimensions [IL10]



Power and Termination Unit Mounting [IL11]

**Power Supply Plug-Pack**

To mount the power supply plug-pack:


- Locate the customer supplied, 240V AC mains supply outlet (within one metre of the PTU)
- Ensure that the outlet is switched OFF
- Attach the plug-pack to the wall using the bracket supplied
- Plug power pack supply into mains outlet.

**Sale/Rental Window**

Refer to the System Order form to determine if the system is sold or rented. Then, before installing each keystation, identify it as follows:

- Remove the latched cover on the keystation base
- For a sold system, pierce the window next to S
- For a rented system, pierce the window next to R
- Only pierce one window on each keystation.
- Replace the cover.

Refer to **Illustration 12 - Sale/Rental Identifying Window**.



**Sale/Rental Identifying Window**  
[IL12]

## Wall Mounting Keystations

To mount a keystation on the wall:

- Obtain a Wall Mounting Kit (WMK-E)
- Push out the handset rest from the centre of the wall mounting bracket and insert it in the hole under the earpiece in the handset


Refer to **Illustration 13 - Installing The Handset Rest.**

- Remove and discard the modular socket cover and locate the modular socket inside the wall bracket
- Remove the centre cut-out of the wall mounting bracket
- Attach the wall mounting bracket to the wall using four screws. *Do not overtighten the screws.*


Refer to **Illustration 14 - Keystation Wall Mounting Dimensions.**

- Connect the short line cord between the socket and the top of the key station
- Clip the keystation into the wall mounting bracket.


Refer to **Illustration 15 - Wall Mounting the Keystation.**



Installing The Handset Rest  
[IL13]



Keystation Wall Mounting Dimensions  
[IL141]



Wall Mounting the Keystation  
[IL15]


## Door Station

To mount a Door Station:

- Remove the base of the Door Station
- Attach the base to the wall using two screws. *Do not overtighten the screws.*

Refer to **Illustration 16 - Wall Mounting Dimensions For Door Stations.**

- Pass the cable through the base using the cable entry at the top of the base
- Attach the Door Station to the base.



Wall Mounting Dimensions For Door Stations  
[IL16]

### Optional Facilities Board Installation (DFB-E)

When the OFB-E is installed in the PTU, it extends the system facilities by providing:


- a Door Station interface
- an external music-on-hold interface
- a background music interface

If any of these facilities are required, the OFB-E must be installed in the PTU.

To install the OFB-E:

- Mount the OFB-E in the PTU cover
- Secure it in place with the four screws provided. Do not overtighten the screws.
- Connect the cable from the OFB-E to the PTB-E.
- Select link for external music (EXT) or internal music (INT) or no music on hold (See page 5-8 for more details).

### Connect and Terminate Cables




Commander **E105/208+** Cabling Scheme  
[IL17]

**Cabling limitations**


The general rules for determining the allowable bus lengths are:

- The overall bus length must not exceed 500 metres
- The total distance of all individual keystations in any one branch emanating from the PTU must not exceed 1000 metres (1 km).

Refer to **Illustration 18 - Bus Length**, and **Illustration 19 - Example of Allowable Keystation Distances**.



**Bus Length**  
[IL181]




**Example of Allowable Keystation Distances**  
[IL19]

**NOTE 1:** ‘Star’ wiring is acceptable provided the above two general rules are followed.

**NOTE 2:** A maximum of eight keystations can be connected to a branch.

Refer to **Illustration 20 - Example of Unacceptable Cabling Scheme**. The overall bus length is acceptable at 500m. However, the individual lengths of branch 2 add up to 1140m. This exceeds the 1000m limit per branch, and therefore makes the cabling scheme unacceptable.


If cabled this way, the system would not function properly. In this case, the PTU should have been located as close as possible to the group of three keystations to create an acceptable overall length.



Example Of Unacceptable Cabling Scheme [IL201]

**Power and Termination Unit (PTU) Terminations**

Terminate the bus on the PTB-E in the PTU. Refer to **Illustration 21 - Power and Termination Unit Terminations**.



Power and Termination Unit Terminations [IL21]

**Power Supply Plug- Pack**

To connect the power supply plug-pack to the Power and Termination Unit:

- Terminate on the input screw terminals J3 1 and J3 2.

**NOTE:** As this is an AC output, it is not polarity-dependent.

**Exchange lines**

To terminate incoming exchange lines:

- Terminate on the PTU on the input screw terminals J2 1 and 2 (line 1), and J2 3 and 4 (line 2).

## Keystations

To cable and terminate the keystations:

- Refer to **Table 2 - Keystation Bus Cabling Terminations**
- After cabling the bus, ensure it is properly terminated and that the polarity is correct.

*Ensure the system is cabled correctly. If it is incorrect, the equipment will not operate.*

It is not important in which order the keystations are connected. However, it is highly recommended that the master keystation be designated extension 1. This simplifies identification for maintenance purposes.

**NOTE:** Terminate the keystations on the modular sockets. Refer to the section - **Modular Socket Termination** below.

PTU TERMINALS	BUS WIRE DESTINATION	WIRE COLOUR	MODULAR SOCKET
J2 11	B1a	White	4
J2 12	B1b	Blue	3
J213	B2a	Orange	6
J2 14	B2b	Green	1
J2 15	Service b (Vb-)	Black	2
J2 16	Service a (Vb+)	Red	5

Table 2 - Keystation Bus Cabling Terminations


## Modular Socket Termination

An MS-E-SMK modular socket is a surface-mounted Krone termination.

To terminate the MS-E-SMK:

- Mount the base and socket PBA assembly
- Cut and strip cable sheath to expose 30mm of conductors
- Lay the appropriate colour conductors across the required terminals and terminate using the standard Krone terminating tool  
Refer to **Illustration 22 - Modular Socket (KRONE Type)**.
- Snap-fit the cover to the socket and base.

**NOTE:** Where termination of a second cable is required, repeat the second and third steps above.



Modular Socket (KRONE Type)  
[IL221]

**Door Station**

To connect a Door Station to the PTU:

- Terminate the two pairs at the Door Station
- Terminate the two pairs on the OFB-E terminal strip J2

Refer to **Table 3 - Door Station Terminations.**

WIRE DESIGNATION	WIRE COLOUR	DESIGNATION DOOR STATION	OFB-E TERMINALS
DR+	Red	DR+	J2 1
DR-	Black	DR-	J2 2
DRA	Blue	DRA	J2 3
DRC	White	DRC	J24

Table 3 - Door Station Terminations

**Power-Fail Telephone**

To cable and terminate a standard two-wire telephone for a power-fail telephone:

- Run the telephone cable directly to the PTU
- Connect the cable on terminals J2 5 and J2 6, or J2 9 and J2 10, on the PTB-E as required.

## Internal Music-On-Hold

Internal music-on-hold is a standard feature of the Commander E105/208+ system. You can disable it on any line if specifically requested by the customer.

To disable internal music-on-hold:

- Locate and remove or park jumper links J3 (line 1) and J4 (line 2) on the HRDB-E board in the master keystation. Refer to **Illustration 31 - Program - Internal, External, and No Music-On-Hold**, page 5-9.

## External Music Source

When the customer requires external music-on-hold or background music, ensure that you install the OFB-E in the PTU to provide the external music source interface.

To connect an external music source:

- Terminate the external music inputs (via the Telstra approved isolation unit) to terminals J2 7 and J2 8 in the PTU
- Locate jumpers J3 (line 1) and J4 (line 2) on the HRDB-E in the Master Keystation
- Move jumper link J3 from pins 1 and 2 to pins 2 and 3
- Move jumper link J4 from pins 1 and 2 to pins 2 and 3.

**NOTE:** For external music sources and external paging devices, relay isolation must be in accordance with Telstra Specification 1364. The device must be:

- Telstra authorised apparatus only
- Authorised specifically for use with a Commander System.

---

## Protective Earth

---

This Commander System no longer requires the mandatory termination of a Telecommunications Reference Conductor (TRC) for high voltage surge protection.

**NOTE:** In lightning-prone areas, protect the exchange lines at their point of entry or distribution in accordance with TPH 0265N0 "Lightning Protection at Customers' Premises" and TPH 02 16 "LSA Plus Terminating System".

---

## General Procedure

---

---

### Power Up

---

To power up the Commander E 105/208+ PTU:

- Ensure the system is cabled and terminated correctly
- Ensure all printed circuit boards are set up and installed correctly
- Switch on power at the plug-pack GPO.

---

### Check Cabling

---

Before installing the keystations, measure the voltage at the modular sockets to ensure that the cabling is correct.

COLOUR	PIN	VOLTAGES
Black	2	Approx. -50V DC
Red	5	0V Ref

Table 4 - Keystation Voltages

---

### Power Down

---

To avoid possible damage to keystations, power down the system before they are connected.

- Switch off power at plug-pack GPO.

---

### Plug in Keystations

---

After testing all sockets to ensure the cabling is correct, plug in all keystations and terminate the Door Station (if required).

---

### Keystation Self Test

---

In Commander E 105/208+ systems, a self test routine is incorporated in the keystation software to assist with their installation and maintenance.

The self test covers:

- speaker
- tone generator
- LEDs and keypad operation.

The self test should be performed on all keystations after they are plugged in.

---

### Test Mode Entry

---

To place the keystation in Test Mode:

- Enter the password

*The password is:*

**[n][7][9][n]**

*where [n] is the keystation address. Therefore, the password for keystation 3 is '3793'.*

The password is only recognised when the keystation is completely idle that is, when:

- it is on-hook
- no system activity is taking place
- all LEDs are OFF.

You must enter the password within four seconds of pressing the first digit. If you do not correctly enter all four digits within four seconds, then you must re-enter the password from the beginning.

**NOTE 1:** The test mode does not check any of the RISC functions, for example, headset and DSS keys.

**NOTE 2:** When Test Mode is exited, the keystation is reinitialised, this will clear all programmed speed dial locations.

### LED Tests

Immediately after entering test mode, all of the keystation LEDs, except RISC LEDs, illuminate for one second, then turn off.

This confirms that all LEDs are working properly.

After the LEDs have turned off, the keystation is in keyboard test mode.

### Keyboard Tests

To test that each key is working correctly, refer to **Table 5 - Self Test Key Sequence and LED Responses**. Enter the keypresses in the sequence shown. The nominated LED will illuminate after you press the key.

Key to Press	LED to Check	Key to Press	LED to Check	Key to Press	LED to Check
[LINE 1]	LINE 1	[1]	LINE 1	[3]	LINE 1
[LINE 2]	LINE 2	[4]	LINE 2	[6]	LINE 2
[SPKR]	SPK	[7]	SPK	[9]	SPK
[DND]	DND	[*]	DND	[#]	DND
[HSET/MODE]	LINE 1	[2]	LINE 1		
[RECALL]	LINE 2	[5]	LINE 2		
[CONF]	SPK	[8]	SPK		
[MEMORY]	DND	[0]	DND		
[REDIAL]	INT				

Table 5 - Self Test Key Sequence and LED Responses

### Audio Circuit Test

At power-up, the confidence tone is automatically enabled. To check this:

- Press any key.

If you hear the confidence tone, the speaker, audio amplifier and DTMF/Tone generator chip are functioning correctly.

**Test Failure**

If a keystation does not function correctly during any of the LED, Keyboard or Audio tests, the line cord and internal ribbon cable should be checked. If the keystation is still faulty, it should be replaced.

**Test Mode Exit**

When the test is complete:

- Go off-hook.

All LEDs will illuminate for one second, then turn off.

---

**Programming**

---

Refer to Chapter Five **-System Programming.**

---

**Defective Equipment**

---

When equipment is defective, you must complete a Customer Equipment Return Analysis Form (Form BS3 1) Available as S3 1 8/3 1.

# **Chapter Five**

## **System Programming**

---

# **Chapter Five**

## **System Programming**

### **Table of Contents**

Introduction .....	5-1
General Description .....	5-1
Programming Hardware locations .....	5-1
DIP Switches .....	5-1
General Programming Procedure .....	5-3
Keystation Intercom Address .....	5-3
Master Page-In .....	5-4
Keystation Access Class .....	5-4
Ring Line 1 .....	5-6
Ring Line 2 .....	5-6
Dial Type .....	5-7
Auto Pause Insert.....	5-7
Music-On-Hold .....	5-8
Background Music .....	5-9
Initialise and Reset .....	5-10
Access Class Restriction .....	5-10
Exchange Line Auto Answer .....	5-11
Headset Mode .....	5-12
Programming Summary .....	5-13
Software Programming Records .....	5-13

---

## Introduction

---

This chapter describes the procedures for programming each feature of the Commander E105/208+ system. A programming summary is also provided at the end of the chapter.

---

## General Description

---

Program the system by setting individual DIP switch positions at each keystation. The DIP switches are located behind a small cover in the base of the keystation.

---

## Programming Hardware locations

---

---

### DIP Switches

---

Program the Commander E 105/208+ system and key stations by setting the DIP switches at each individual keystation.


There are two DIP switches:

- DIP Switch 1 (SW 1) a four-way switch for setting the keystation address. The four switch positions are:  
SW 1.1    SW 1.2    SW 1.3    SW 1.4
- DIP Switch 2 (SW2) an eight-way switch for setting system and keystation options. The eight switch positions are:  
SW 2.1    **SW 2.2**    SW 2.3    SW 2.4  
SW 2.5    SW 2.6    SW 2.7    SW 2.8

To access the switches:

- Using a small flat screwdriver, remove the small cover underneath the keystation.

Refer to **Illustration 23 - Keystation DIP Switches (In Default Settings)**.



SWITCH NUMBER	OPTION	SETTING
SW2.1	MASTERPAGEIN	 enabled  disabled
sw2.2	UNRESTRICTEDACCESS	 enabled  disabled
SW2.3	RING - LINE1	 enabled  disabled
SW2.4	RING - LINE2	 enabled  disabled
SW2.5	DIAL TYPE	 decadic  DTMF
SW2.6	NOT USED	 
SW2.7	NOT USED	 
SW2.8	AUTO PAUSE INSERT	 enabled  disabled

Table 6 - DIP Switch 2 Keystation Options

## General Programming Procedure

### Keystation Intercom Address

Assign the keystation addresses at each keystation by setting SW 1.

To set the keystation address:

Refer to **Table 7 - Keystation Address Settings**.

RTERCOM EXTENSION	SW 1.1	sw1.2	osw1.3	sw1.4
1	0	0	0	1
2	0	0	1	0
3	0	0	1	1
4	0	1	0	0
5	0	1	0	
6	0	1	1	0
7	0	1		
8	1	0	0	0

NOTE: 1 = ON 0 = OFF

Table 7 - Keystation **Address Settings**


**Master Page-h**

To program a keystation to receive an “All Call Page” and the Door Station chime:

- Set SW2.1 to ON.

To disable these facilities:

- Set SW2.1 to OFF.

**Example**

No Master Page-h  
[IL24]

**Keystation Access Class**

Two outgoing line access classes are available for Commander E 105/208+ keystations:

- Class 1 - unrestricted calls
- Class 2 - local calls only.

Program each keystation's access class with SW 2.2.

NOTE: This switch is password protected. Refer to Page 5- 10 for full details of password.

**Class 1**

- To program a keystation for Class 1:
- Set SW 2.2 to ON.

Class 1 keystations have unrestricted access allowing any number of digits to be dialled.

**Class 2**

To program a keystation for Class 2:

- Set SW 2.2 to OFF.

In this mode, all numbers dialled are compared to an exception table. The basis of the table is that all dial input is compared to entries in the table, and if no match is found the call is barred (i.e. all numbers are barred, with the exception of.. .)

The exception table consists of two areas: A non-programmable area, with fixed emergency numbers etc, and a programmable area consisting of 8 entries of 4 digits each. At default, the programmable table is set to 'no exceptions'.

To program entries into the exception table, proceed as follows:

1. Enter [n][7][9][n+1] (where 'n' is the keystation address).  
Therefore the password for keystation 3 would be 3794.
2. Press [MEMORY], followed by the table number ([1] through to [8]).
3. Enter the exception code (up to 4 digits).
4. Repeat steps 2 and 3 until complete
5. Go off-hook then on-hook.

Exception table entries may be up to 4 digits long. The more digits entered, the more restricted will be the exceptions that can be dialled. In the example given below, a Melbourne user is restricted to Melbourne metro, Port Augusta, Queensland, Wollongong and AMPS (the example is based on the 10 digit AUSTEL numbering plan).

\* INCLUDE A 9 IN EXCEPTION TABLES FOR 8 DIGIT NUMBERS.  
RESTRICTED ACCESS ONLY  
ARRS CALLS > 6 DIGITS? 7?

Table location	Entry	Allows
1	[9]	Allows calls within Melbourne (9XXX xxxx)
2	[0][8][8][6]	Allows calls to Port Augusta ((08) 86XX XXXX)
3	[0][7]	Allows calls to Queensland and surrounding areas ((07) xxxx XXXX)
4	[0][2][4][2]	Allows call to Wollongong ((02) 42XX XXXX)
<b>5</b>	[0][1][8]	Allows calls to AMPS (018)XXX XXX)
6	[*]	No exceptions allowed
7	[*]	No exceptions allowed
6	[*]	No exceptions allowed

Table 8 - Example of Exception Table


The example demonstrates that adding more digits to an exception table entry 'tightens up' the number range of available destinations. Entry 2 will restrict calls to Port Augusta, while entry 3 will allow most of Queensland. To tighten entry 2 to the Sunshine Coast only for example, the entry would become [0][7][5][4]. An entry consisting of a '\*' only, effectively means 'no exceptions are allowed'.

To clear an entry:

- Enter '\*' at step 3 above.

The non programmable area of the table contains the following:

000, 008n, 18n, 016n, 0175, 122n, 1144n, 13n, 013.

**Example**

Program - Class 2  
[IL251]


**Ring line 1**

To enable calls to ring on incoming exchange line 1:

- Set SW 2.3 to ON.

To disable calls ringing on incoming exchange line 1:

- Set SW 2.3 to OFF.

**Example**

Program - Ring On line 1  
[IL261]


**Ring line 2**

To enable calls to ring on incoming exchange line 2:

- Set SW 2.4 to ON.

To disable calls from ringing on incoming exchange line 2:

- Set SW 2.4 to OFF.

**Example**

Program - No Ring On line 2  
[IL27]


---

**Dial Type**

---

To select keystation for Decadic dialling:

- Set SW 2.5 to ON.
- To select keystation for DTMF dialling:
- Set SW 2.5 to OFF.

**Example**

Program - OTMF **Dialling**  
[IL28]

---

**Auto Pause Insert**

---


This option allows the keystation to insert automatically a three-second pause when using redial or abbreviated dialling on PABX lines.

To enable the three-second pause:

- Set SW 2.8 to ON.

To disable the three-second pause:

- Set SW 2.8 to OFF.

**Example**

Program - Auto Pause Insert  
[IL29]

**Music-On-Hold**

This program facility allows the following options:


- internal music-on-hold
- external music-on-hold
- no music-on-hold.

Program this facility by positioning the links on the Hold And Ring Detect Board (HRDB-E) in the system master keystation and in the Optional Facilities Board (OFB-E).

To access the HRDB-E:

- Unscrew the five screws underneath the keystation and remove the keystation cover
- Disconnect the keystation speaker
- Unplug the ribbon cable
- Unscrew the keystation board centre securing screw and remove the board.

To find the position of the links on the HRDB-E, refer to **Illustration 30 - Music-On-Hold Links**.



Music-On-Hold links  
[IL301]

MUSK: SOURCE	UNKS ON LINE 1	HRDB-E LINE 2	LINK ON OFB-E
	J3	J4	J3
INTERNALCHIMES	1&2	1&2	INT
EXTERNALMUSIC	2&3	2&3	EXT
NO MUSIC	PARK ON 1	PARK ON 1	INT

Table 9 - Music Source links

**Examples**




Program - internal, External, and No Music-On-Hold  
[IL311]

To access the OFB-E:

- Remove the PTU cover
- Position the jumper for the required setting.

**NOTE:** The setting of this jumper (J3) must be consistent with the setting of the jumper on the HRDB-E.

**Examples**



External Music-On-Hold  
Setting on OFB  
[IL321]

internal or No **Music-On-**  
Hold Setting on OFB  
[IL33]

**Background Music**

To program the system for background music:

- Set the OFB-E to external music-on-hold
- Set the HRDB-E to external music-on-hold

For further details, see the previous section Music-On-Hold.

---

## Initialise and Reset

---

Upon power on, an initialising routine sets up the logical and physical settings of the keystation microcomputer.

The DIP switches are scanned and internal system flags are set/reset according to the DIP switch settings.

If a change is ever made to the DIP switch settings, the keystation must be reset for the new settings to be recognised.

There are two ways to reset the keystation:

- Power system OFF, then power ON,
- or*
- Remove, then re-insert, the keystation's line cord
  - With either method, wait approximately 10 seconds for the system to initialise.

---

### Access Class Restriction

---

The STD/IDD barring DIP switch has special protection.

If the setting is changed, a password must be entered on the keypad to initiate a scan of this switch and to reset it. This procedure prevents unauthorised personnel changing the keystation access class.

This password is:

[n] [7] [9] [n]

where [n] is the keystation address. Therefore, the password for keystation 3 would be '3793'.

The password is only recognised when the keystation is completely idle that is, when:

- the keystation is on-hook
- no system activity is taking place
- all LEDs are off.

Refer to page 5-4 for programming of exception table.

Enter the password within four seconds of when you press the first digit. If you do not correctly enter all four digits within four seconds, re-enter the password from the beginning.

Exit by going Off-hook.

**NOTE:** This password is confidential and should not be told to the customer or to anyone else outside Telstra.

---

## Exchange line Auto Answer

---

This option provides automatic answering of ringing exchange line calls. Ringing calls are answered simply by lifting the handset - there is no necessity to press the [LINE] key.

If more than one call is ringing, lifting the handset will answer the oldest ringing call.

To enable Exchange Line Auto Answer:

- Enter the keypad features password.

The password is only recognised when the keystation is completely idle that is, when:

- the keystation is on-hook
- no system activity is taking place
- all LEDs are off.

The password is:

[n][7][9][n+1]

where [n] is the keystation address. Therefore, the password for keystation 3 would be '3794'.

**NOTE:** This password differs from the Access Class Restriction Password.

*All LEDs will flash once.*

- Press [MEMORY][9][\*]
- Press [1]
- Exit by going off-hook.

*All LEDs will flash once.*

To disable Exchange Line Auto Answer:

- Enter keypad features password as described above
- Press [MEMORY] [9] [\*]
- Press [0]
- Exit by going off-hook.

*All LEDs will flash once.*

---

**Headset Mode**

---

Headset Mode programming is a keystation user level option, and is included here for completeness only.

A keystation handset may be replaced by a suitable Austel permitted headset. When connected and activated, the [SPKR] key is used to perform the off-hook function. Headset Mode is protected against accidental activation and de-activation by a two-key activation sequence.

To activate Headset Mode:

- Press and Hold [HSET/MODE]
- Press and Release [SPKR].

To deactivate Headset Mode:

With the handset on-hook,

- Press and Hold [HSET/MODE]
- Press and Release [SPKR].

Once activated, Headset Mode is selected as follows:

To select Headset Mode:

- Press [HSET/MODE]
- The [HSET/MODE] key will glow.

To de-select Headset Mode:

- Press [HSET/MODE]
- The [HSET/MODE] key will go out.

**NOTE 1:** When Headset Mode is selected, the handset function is controlled by pressing the [SPKR] key.

**NOTE 2:** When in Headset Mode, the station cannot be operated in off-hook mode.

## Programming Summary

PROGRAM POINT	FACILITY/ OPTION	ASSIGNMENT	INITIAL VALUE
OIP Switch 1	Station Address	1.1 1.2 1.3 1.4	
(each keystation)	Extension 1	off off off on off off on off off off on on off on off off off on off on off on on off off on on on on off off off	off off off on
OIP Switch 2			
2.1	Master Page In	on enable off - disable	ON
2.2	Unrestricted Access	on enable off - disable	ON
2.3	Ring Line 1	on enable off - disable	ON
2.4	Ring Line 2	on enable off - disable	ON
2.5	Dialling type	on - Decadic off DTMF	ON
2.6	Not Used		
2.7	Not Used		
2.8	Auto pause insert	on enable off - disable	OFF
Links J3 and J4 HRDB-E (Master keystation)	Line 1 Internal M.O.H. Line 1 External M.O.H. Line 1 No M.O.H. Line 2 Internal M.O.H. Line 2 External M.O.H. Line 2 No M.O.H.	J3 1 & 2 2 & 3 park J4 1 & 2 2 & 3 park	1 & 2   1 & 2

### Software Programming Records

Place a copy of the system program in the PTU as a record of the way the system has been programmed.

# **Chapter Six**

## **Functional Tests and Maintenance**

---

**Chapter Six**  
**Functional Tests and Maintenance**  
**Table of Contents**

Introduction .....	6-1
General Description .....	<b>6-1</b>
System Tests and Repair Actions .....	6-2
Keystation Installation .....	6-2
* Exchange Line Seizure .....	6-3
* Incoming Exchange Call .....	6-3
Off-Hook Signalling .....	6-3
Volume Control .....	6-3
Answering Exchange Call .....	6-3
Automatic Answering Exchange Call .....	6-4
* Outgoing Exchange Call .....	6-4
Decadic to Tone Signalling .....	6-4
Hold .....	6-4
Music-On-Hold .....	6-4
Hold Automatic Ring Back .....	6-4
* Last Number Redial .....	6-4
Abbreviated and Speed Dialling .....	6-5
System Memory Back-Up .....	6-5
* PABX Recall .....	6-5
* Paging .....	6-5
Do Not Disturb .....	6-5
Intercom Signal or Voice Call .....	6-5
Intercom Answering .....	6-5
On-Hook Dialling .....	6-5
* Exchange Line Conference .....	6-6
* Background Music .....	6-6
* Door Station .....	6-6
* Power-fail Telephone .....	6-6
Centel Features .....	6-6
<b>Maintenance</b> .....	6-7
Test Equipment .....	6-7
Voltage Test Points .....	6-7
Power Supply Plug-Pack .....	6-7
Power and Termination Unit .....	6-7
Keystations .....	6-7

General .....	6-8
System Plug-Pack.....	6-8
Power and Termination Unit .....	6-8
Keystations.. .....	6-8
<b>Fault Finding Tables .....</b>	<b>6-8</b>
<b>Repair Procedures .....</b>	<b>6-15</b>
Printed Board Assemblies (PBA's) .....	6-15

# Chapter Six

## Functional Tests and Maintenance

---

### Introduction

---

This chapter provides all the information required to test and repair the Commander E 105/208+ keystations and system.

---

### General Description

---

Test the system after:

- installing it
- performing the keystationself-test
- performing the programming procedures.

Test the system in accordance with the test procedures listed in this chapter. If you encounter a fault, follow the repair actions.

This chapter also provides a comprehensive set of fault finding ables, system tests and repair actions to use for system maintenance.

#### **CAUTION**

Each test consists of a special sequence of steps. Do not perform any other action - for example, going on-hook - between the steps. If a fault interrupts the test, follow the repair suggestion(s), then restart the test at the beginning of the relevant section.

---

## System Tests and Repair Actions

---

The system functions are listed in a test sequence. Test the system in this order whilst consulting the System User Guide (Appendix C) for correct operation of the functions. If a fault interrupts the test sequence, restart the test at an entry point marked \*.

---

### Keystation Installation

---

Check:

- the system has power
- bus wiring to the keystation

Refer to **Table 10 - Cable Connections**.

- voltage on the wires to the keystation with all keystations not connected.

Refer to **Table 10 - Cable Connections**.

*If a voltage is not similar to that listed in Table 10, check the plug-pack and PTU.*

WIRE	MOO. SOCKET NUMBER	VOLTAGE
Green	1	Line 2 b
Black	2	Service B - 50V
Blue	3	Line 1 b
White	4	Line 1 a
Red	5	Service A - 0V
Orange	6	Line 2 a

Table 10 - Cable Connections

---

**Commence tests here**

---

\* Exchange line Seizure

Dial tone received and line lamp on. If not, check:

- exchange line at PTU line terminals
- exchange line at PTU bus terminals

*If line is not present, replace the PTU.*

- bus wiring and voltage

Refer to **Table 10 - Cable Connections.**

- keystation internal ribbon cable connection
- keystation line cord and handset.

*If fault still exists, repluce the keystation.*

\* Incoming Exchange Call

If the signal is not heard, check:

- master keystation is installed
- DND key is off
- keystation 'Ring Line 1' and 'Ring Line 2' programs
- bus wiring.

*If fault still exists, replace the HRDB-E or muster keystation.*

If a fault still exists, check:

- keystation speaker lead connection.

*If fault still exists, replace the keystation.*

Off-Hook Signalling

If the signal is not heard, check:

- keystation speaker lead connection.

*If fault still exists, replace the keystation.*

Volume Control

Adjustable low to high.

*If not, replace the keystation.*

Answering Exchange Call

If an incoming call is not seized, check:

- bus wiring
- keystation line cord and handset
- keystation ribbon cable connection

*If a fault still exists, repluce the keystation.*

---

**Automatic Answering  
Exchange Call**


---

If an incoming call is not seized when the handset is lifted, check:

- as for 'Incoming Exchange Call'
- keypad features programming

---

**\* Outgoing Exchange Call**


---

If the correct number is not reached, check:

- keystation 'Unrestricted Access' program
- keystation 'Dial Type' program

Test the exchange line

*If the fault still exists, replace the keystation.*

---

**Decadic to Tone  
Signalling**


---

If the tone signalling is not heard after pressing [MODE], replace the keystation.

---

**Hold**


---

If an exchange call does not hold, check:

- keystation ribbon lead connection.

*If fault still exists, replace the HRDB-E or master keystation.*

*If fault still exists, replace the keystation.*

---

**Music-On-Hold**


---

Determine the music source.

- Check J3 for Line 1 and J4 for Line 2 on the HRDB-E.

*Position 1 & 2 - Internal music.*

*Position 2 & 3 - External music.*

For external music source, check:

- Music source and its connection to the PTU

*If you cannot hear the source at the 610 socket, liability for repair lies with the customer.*

- OFB-E is correctly installed and jumper (J3) is set correctly.

*If fault still exists, replace the OFB-E.*

---

**Hold Automatic Ring Back**


---

If ring back does not occur after 90 seconds, replace the keystation.

---

**\* Last Number Redial**


---

If the system is connected to a PABX, and the correct number is not obtained, check:

- keystation 'Auto-Pause Insert' program.

*If fault still exists, replace the keystation.*

**Abbreviated and Speed  
Dialling**

If the correct number is not obtained, check:

- correct procedure is being used to store numbers
- stored number does not violate access barring class in keystation 'Unrestricted Access' program.

If system is connected to a PABX, check:

- Auto-Pause Insert' program.

*If fault still exists, replace the keystation.*

**System Memory Back-Up**

If last number dialled and abbreviated numbers are not retained, replace the keystation.

**\* PABX/Centel Recall**

PABX/Centel recall is not effective.

If TLB is not effective:

- remove PABX/Centel line from PTU and connect to Touchfone® 200.
- exercise features that are controlled by Recall.

*If feature works as expected, but fault still exists when the line is reconnected to the PTU, replace the keystation.*

**\* Paging**

If pages are not received, check:

- keystation 'Master Page - In' program.

*If fault still exists, replace the keystation.*

**Do Not Disturb**

If calls are not blocked, replace the keystation.

**Intercom Signal or Voice  
Call**

If an intercom call is not heard, check:

- called keystation 'Intercom Address' program
- called keystation speaker lead connection
- bus wiring.

*If fault still exists, replace the keystation.*

**Intercom Answering**

If the speech path is not present, check:

- keystation handset.

*If fault still exists, replace the keystation.*

**On-Hook Dialling**

If the dial tone is not heard, check:

- bus wiring
- keystation speaker lead connection.

*If fault still exists, replace the keystation.*

---

**\* Exchange line  
Conference**

---

If a conference is not established, replace the keystation.

---

**\* Background Music**

---

If music is not heard, check:

- music source and its connection to the PTU  
*If music is not heard at the 610 socket, liability for repair lies with the customer:*
- OFB-E is correctly installed.  
*If fault still exists, replace the OFB-E.*  
*If fault still exists, replace the keystation.*

---

**\* Door Station**

---

Hear chime, and speech path is present. If not, check:

- keystation 'Master Page-In' program
- wiring at Door Station and OFB-E
- OFB-E flat cable connector.  
*If fault still exists, replace the OFB-E.*  
*If fault still exists, replace the keystation.*

---

**\* Power-fail Telephone**

---

Line 1 at power-fail telephone during power failure? If not, check:

- exchange line at PTU power-fail terminals  
*If line is not present, replace the PTU.*
- wiring at PTU and telephone socket.  
*If fault still exists, replace the power-fail telephone.*

---

**Centel Features**

---

If Centel features do not work as expected:

- Check that correct feature Key/s are being used on the keystation.  
Refer to Keystation User Guide, and Centel User Guide.
- Try accessing the Centel feature/s at another keystation.  
*If Centel features work as expected when another keystation is used, replace the keystation.*
- Remove Centel line from PTU and connect to Touchfone 200. Exercise Centel features manually using the Touchfone 200. If features do not work as expected when the Touchfone 200 is used, have the network programming checked.

## Maintenance

### Test Equipment

Use the following equipment to maintain the Commander E 105/208+ system:

A multimeter with small test probes to measure various test voltages and to test wiring continuity between the PTU, connectors and keystations.

Normal maintenance tools such as long-nose pliers, angle cutters, a Philips-head screwdriver and flat-blade screwdriver.

Where Centel lines are connected, a test telephone equipped to generate \*, # and 1 00mS TLB.

### Voltage Test Points

Voltages should be measured under 'no-load' conditions that is, with all keystations unplugged.

### Power Supply Plug-Pack

The power supply plug-pack supplies AC Voltage to the PTU.

Measure the voltages on the PTU input terminal strip. Refer to **Table 11 - Power Supply Test Points.**

LOCATION	TEST POINT	VOLTAGE
PTB-E	Power Supply Input terminals J3.1 and J3.2	Between 17V AC and 31V AC

Table 11 - Power Supply Test Points

### Power and Termination Unit

The Power and Termination Unit supplies DC Voltage to the System Bus. Measure these voltages on the PTU terminal strip at J2 15 and 16. Refer to **Table 12 - Power and Termination Unit Test Points.**

LOCATION	WIRECOLOUR	TEST POINT	VOLTAGE
PTU (J2)	Black	Output terminal 15	Approx. -50V DC
	Red	Output terminal 16	OVREF

Table 12 - Power and Termination Unit Test Points

### Keystations

Measure keystation bus voltage at terminals 2 and 5 in the keystation modular socket. Refer to **Table 13 - KeystationTest Points.**

LOCATION	WIRECOLOUR	TEST POINT	VOLTAGE
Keystation Modular Socket	Black	Terminal2	Approx. -50V DC
	Red	Terminal5	OVREF

Table 13 - KeystationTest Points

---

**General**

---

The amount of maintenance that can be carried out on Commander E105/208+ equipment is limited to changeover of the PTU and replacement of keystation parts. This is due to the susceptibility of the components to damage by static discharge (especially MOS components).

To protect faulty assemblies and items such as the power supply, PTU and keystation, transport them in the protective container supplied with the new item. Before returning faulty equipment, refer to the section entitled Repair Procedures at the end of this chapter.

**System Plug-Pack**

When the power supply plug-pack is diagnosed as being faulty, it must be replaced with a maintenance spare.

**CAUTION**

The system plug-pack is powered from a 240V mains supply and hazardous voltages are present within.

When replacing the system plug-pack, before disconnecting it from the PTU terminal strip J3, ensure that:

- the mains outlet is switched off
- the plug pack is removed from the outlet.

**Power and Termination Unit**

Any fault on the PTB-E requires replacement of the entire PTU.

Any fault on the OFB-E (where fitted) requires that it be replaced with a maintenance spare. Do not carry out repairs on site as further damage to the board may result.

**Keystations**

Keystation maintenance is confined to replacing the handset, line cord and HRDB-E board (in the master keystation). To rectify a keystation PBA or keyboard assembly fault, replace the complete keystation.

## Fault Finding Tables

The following tables provide an orderly set of steps for rectifying faults in an established working system. The 'fault number' indicates the order to follow when performing the diagnosis and repair procedures.

### INCOMING EXCHANGE LINE FAULTS

Fault No.	Fault Description	TEST/REPLACEMENT SEQUENCE IN PREFERRED ORDER					Other Procedures
		Station	P.T.U.	OFB-E	HRDB-E or Master Station	Plug Pack	
1	No audible incoming line signal (line lamp flashes). One station only.	2					1. Check ring assignment
2	No audible incoming line signal (line lamp flashes). More than one station.	4	3				1. Check ring assignment. 2. Check bus wiring.
3	No incoming line signal (audible or visual). One station only.	3			4		1. Check exchange line wiring. 2. Replace line cord.
4	No incoming line signal (audible or visual). More than one station.	5	4		1		2. Check exchange line wiring. 3. Check bus wiring.
5	Line lamp does not flash with exchange ring (audible signal received). One station only.						2. Check bus wiring.
6	Line lamp does not flash with exchange ring (audible signal received). More than one station.	3	2				1. Check bus wiring.

### OUTGOING EXCHANGE LINE FAULTS

Fault No.	Fault Description	TEST/REPLACEMENT SEQUENCE IN PREFERRED ORDER					Other Procedures
		Station	P.T.U.	OFB-E	HRBB-E or Master Station	Plug Pack	
7	Exchange line cannot be seized. One station only.	2					1. Replace tine cord.
8	Exchange line cannot be seized. More than one station.	4	3				1. Check incoming exchange line terminations. 2. Check bus wiring.
9	Line lamp does not light when exchange line seized One station only.	2					1. Replace line cord.
10	Line lamps do not light when exchange line seized. More than one station.		3			4	1. Check Incoming exchange line terminations. 2. Check bus wiring.
11	No dial tone when exchange line seized. Any station.	2					1. Check handset.
12	Exchange line call cannot be performed. One station only.	1					2. Check bus wiring. 3. Check access barring classes.
13	Exchange line call cannot be performed.		2				1. Check bus wiring. 3. Check access barring classes.
14	No PABX recall on a station.	1			2		1. Check station settings.

OTHER EXCHANGE LINE FAULTS

Fault No.	Fault Description	TEST/REPLACEMENT SEQUENCE IN PREFERRED ORDER					Other Procedures
		Station	P.T.U.	OFB-E	HRDB-E or Master Station	Plug Pack	
15	Exchange line cannot be put on hold. One station only.	2			1		1. Replace line cord.
16	Exchange line cannot be put on hold. More than one station.				1		
17	Line does not flash on hold. Any station.	1			2		
18	No internal music on hold. Any station.	3			2		1. Check links J3 and J4 are in correct position on HRDB-E (pos. 1-2).
19	No external music on hold.	5		4			1. Check external music source 2. Check external music source terminators. 3. Check links J3 and J4 are in correct position on HRDB-E (pos. 1-2).
20	Exchange line cannot be release by hook switch operation. Any station.	1					
21	Exchange line not release by speaker key with handset on hook. Any station.	1					

### TELEPHONE STATION FAULTS

Fault No.	Fault Description	TEST/REPLACEMENT SEQUENCE IN PREFERRED ORDER					
		Station	P.T.U	OFB-E	HRDB-E or Master Station	Plug Pack	Other Procedures
22	Abbreviated or speed dialling does not function. Any station.	1					
23	Do Not Disturb does not function. Any station.	1					
24	Decadic to tone signalling mode change does not function. Any station.	1					
25	Last number redial does not function, Any station.	1					
26	Volume Control does not function. Any station.	1					
27	Confidence tone does not function. Any station.	1					
28	Access Barring does not function. Any station.	2					1. Check station programming.
29	Memory loss immediately after a power failure. Any station.	1					

### INTERCOM CALL FAULTS

Fault No.	Fault Description	TEST/REPLACEMENT SEQUENCE IN PREFERRED ORDER					
		Station	P.T.U.	OFB-E	HRDB-E a Master Station	Plug Pack	Other Procedures
30	Intercom signal does not function. One station only.	1					
31	Intercom signal call does not function. More than one station	2	3			4	Check bus wiring.
32	Intercom voice call does not function. One station only.	1	2				
33	Intercom voice call does not function. More than one station.	2	3			4	Check bus wiring.
34	Intercom lamp does not flash on incoming call. Any station.	1					

### CALL PAGE FAULTS

Fault No.	Fault Description	TEST/REPLACEMENT SEQUENCE IN PREFERRED ORDER					
		Station	P.T.U.	OFB-E	HRDB-E a Master Station	Plug Pack	Other Procedures
35	Page call does not function. One station.	2					1. Check station is programmed for Master Page access.
36	Page call does not function. More than one station.	3	2				1. Check stations are programmed for Master Page access.

**DOOR STATION AND OPTIONAL FACILITY FAULTS**

Fault No.	Fault Description	TEST/REPLACEMENT SEQUENCE IN PREFERRED ORDER					
		Station	P.T.U.	OFB-E	HRUB-E a Master Station	Plug Pack	Other Procedures
37	Door Station call cannot be performed.			1			2. Replace Door Station.
38	Door Station call not received at. One station only.	2		3			1. Check station is programmed for Master Page access.
39	Door Station call not received at. More than one station.		4	2			1. Check station is programmed for Master Page access. 3. Replace Door Station
40	Background music not functioning.		3	2			1. Check external music source and external music source terminations,

**TRANSMISSION AND POWER FAULTS**

Fault No.	Fault Description	TEST/REPLACEMENT SEQUENCE IN PREFERRED ORDER					
		Station	P.T.U.	OFB-E	HRUB-E a Master Station	Plug Pack	Other Procedures
41	Poor transmission and/or reception. One station only	2					2. Check handset
42	Poor transmission and/or reception. More than one station.		2				1. Check bus wiring.
43	No power to system.		3			2	1. Check fuse F1 on PTB-E.

**MICELLANEOUS FAULTS**

Fault No.	Fault Description	TEST/REPLACEMENT SEQUENCE IN PREFERRED ORDER					
		Station	P.T.U.	OFB-E	HRUB-E a Master Station	Plug Pack	Other Procedures
44	Conference call not possible.	1	2				
45	Transferring calls not possible.	1	2				

---

## Repair Procedures

---

Repair of Commander E105/208+ systems is limited to replacing PBA's and the spare parts as listed in Appendix B - Field Maintenance Parts.

Always pack faulty items in the carton and packaging supplied with the new item. Forward the package to your local store, where it is then sent to the National Repair Centre.

---

### Printed Board Assemblies (PBA's)

---

Do not attempt to repair a PBA on site or in a field depot. Any fault in a PBA requires replacement of the entire assembly.

Pack a faulty PBA in the same carton and packaging supplied with the new assembly. Forward the package to your local store, where it will then be sent to the National Repair Centre.

NOTE: Customer Equipment Return Analysis Form (BS3 1)  
S818/3 1

PBA's. Write as many details of the fault condition as possible on the label.

# **Appendix A**

## **System Characteristics**

---

# Appendix A System Characteristics

---

## System Capacities and limits

---

	<b>E105+</b>	<b>E208+</b>
BUS Wires Required	4	6
BUS Limit (0.5MM Cable)	500M	500M
Exchange Lines	1	2
Intercom Lines	1	1
Keystations	5	8
Door Stations	1	1
Paging Zones	1	1
Access Barring Classes	2	2

## System Specifications

### Electrical

AC input to Power Supply	240 VAC 50 Hz
Power Consumption	25 Watts
Output Voltage	50 DC Nominal
Bus Cable Length (Twisted Pair)	500 metres of .5mm dia. cable

### Environmental

Operating Temperature	10 C to 55 C
Humidity (Relative)	45 to 75%
Storage Temperature	7oc

### External Music- On-Hold

Nominal Input Level	6 Vu
---------------------	------

### Dialling

#### DTMF (Tone) Dialling

Frequency Deviation	1.5%
Duration	100ms
Interdigit pause	100ms

#### Pulse (Decadic) Dialling

Pulse Dialling rate	10pps
Break Make Ratio	66/33 (2:1)
PABX Pause	3 seconds
PABX Recall	100±40 ms

### Dimensions and Weight

Equipment	Weight	Height	Width	Depth
Keystation	0.9kg	8mm	185mm	235mm
Power Termination Unit	0.5kg	162mm	185mm	60mm
Door Station	0.2kg	160mm	110mm	37mm

**Appendix B**  
**Parts Serial Item and Code list**

---

## Appendix B Parts Serial Item and Code list

### Central Equipment

Serial 546

ITEM & CODE	DESCRIPTION	REMARKS
1 PTU-E	Power and Terminating Unit	Includes plug power-pack; provides termination point for incoming lines, system bus, power-fail telephone, external music source and Door Station. Houses the optional facilities board PBA (if required).
5 OFB-E	Optional Facilities Board	Optional PBA, housed in the PTU. Provides Door Station interface, external music-on-hold, background music and earth recall facilities.

### Keystations

Serial 546

ITEM & CODE	DESCRIPTION	REMARKS
209 TS-E105+-M	One-line Keystation Master	One-line Keystation. Contains the system hold and ring detect board (HRDB-E), system user guide, (item 62), keystation user guide (item 60) and keystation label card.
210 TS-E208+-M	Two-line Keystation Master	Two-line Keystation. Contains the system hold and ring detect board (HRDB-E), system user guide (item 62), keystation user guide (item 60) and keystation label card.
212 TS-E208+-S	Two-line Keystation Standard	Two-line keystation. Contains the keystation user guide (item 60) and keystation label card.
13 DSE	Door Station	Four-wire Door Station. Terminates on OFB-E in PTU.

### Miscellaneous Items

ITEM & CODE	DESCRIPTION	REMARKS
5461221 WMK-E+	Wall Mounting Kit	For wall-mounting a Commander Et keystation. Includes a handset securing piece, a 30cm line cord and a mounting instruction card.
268/125 SMK-(6x6)-CON	Krone	WE type, six-wire socket.

**Maintenance Parts****Serial 546**

ITEM & CODE	DESCRIPTION	REMARKS
32 LC-E-6W	Line Cord, Six-Wire	Six-conductor line cord terminated with modular plugs on each end. Maintenance part for all keystations (items 9-12).
233 HS-EP	Handset With Cord	Handset with integral handset cord. Maintenance part for all keystations (items 9-12).
234 SLP-EP	Station Label Pack	Pack of ten keystation label cards. Each card contains three adhesive keystation directory labels for all keystations (item 9-12).
35 PP-E	Power-Pack	System plug power pack. Maintenance part for system PTU (item 1).
36 HRDB-E	Hold and Ring Detect Board	PBA housed in master keystation to provide ring detect and music-on-hold. Maintenance part for master keystations (items 9 and 10).

**Documents****Serial 546**

ITEM & CODE	DESCRIPTION	REMARKS
200	Centel/Easycall Quick Reference Card	
203	System Order Form	
260 DOC-EP-UG	Keystation User Guide	A quick reference card, included with all keystations (items 9-12). NOTE: Item 60 consists of a box of 50
261 DOC-EP-IM	Installation and Maintenance Manual	Complete installation and maintenance procedures for the Commander E105/208+ small business system.
262 DOC-EP-SG	System User Guide	Complete system user guide. One provided per system, included with the system Master Keystation.
263	Product Sales Reference Manual	
265	Customer Record Card	
264	Sales Brochure	

# **Appendix C**

## **System User Guide**

---

Telstra Commander@ **E1 05/208+**  
System- User Guide

---

Serial Item 546/262

Issue 1



## Table of Contents

<b>1. Getting to Know Your Commander</b> .....	<b>1-1</b>
Keystation Diagram .....	1-2
Key Description .....	1-3
Visual Signals .....	1-d
Audible Signals .....	1-d
Service Tone .....	1-S
Access Barring .....	1-S
Centel Features .....	1-6
<b>2. Answering Calls</b> .....	<b>2-1</b>
Intercom Calls .....	2-2
Ring at Your Station .....	2-2
Ring at Another Station .....	2-2
Outside Calls .....	2-2
Door Station Calls .....	2-3
<b>3. Making Calls</b> .....	<b>3-1</b>
Intercom Calls .....	3-2
Intercom Signal Call .....	3-2
Intercom Voice Call .....	3-2
Outside Calls .....	3-3
Off-hook Dialling .....	3-3
On-hook Dialling .....	3-3
Last Number Redial .....	3-d
Speed Dialling .....	3-d
Abbreviated Dialling .....	3-S
Door Station Calls .....	3-S

<b>4. Holding and Transferring Calls</b> .....	<b>4-1</b>
Holding Calls .....	4-2
Transferring Calls .....	4-3
<b>5. Paging and Conference Calls</b> .....	<b>5-1</b>
Paging .....	5-2
All-Station Page .....	5-2
Meet-Me Page .....	5-3
Conference Calls .....	5-d
Conference with an Outside Party .....	5-d
Intercom Conference .....	5-s
<b>6. Centel Features</b> .....	<b>6-1</b>
Call Back .....	6-2
Call Diversion .....	6-3
Call Diversion - Immediate .....	6-3
Call Diversion - Busy .....	6-d
Call Diversion - No Answer .....	6-S
Call Waiting .....	6-7
Call Transfer .....	6-8
Call Conference .....	6-9
<b>7. Other Facilities</b> .....	<b>7-1</b>
Storing Speed Dial Numbers .....	7-2
Storing Abbreviated Dial Numbers .....	7-3
Confidence Tone .....	7-3
Decadic to Tone Signalling .....	7-d
Background Music .....	7-d
Do Not Disturb .....	7-S
PABX Recall .....	7-S
Headset Mode .....	7-6

)


---

<b>8. General Information</b> .....	<b>8-1</b>
Care of Your Commander .....	8-2
Service Problems .....	8-2
Power Failure .....	8-2
Other Difficulties .....	8-3
System Enhancement . . . . .	8-3

**1. Getting to Know  
Your Commander**

---

## Keystation Diagram



## Key Description

### 1 HSET/MODE Key

a) Headset Mode Activation

b) Dialling Mode Change

Change from decadic to tone signalling after a call is established.

### 2 LINE Key

To access outside line.

### 3 SPEAKER Key

To activate the speaker - calls can be initiated without lifting handset,

### 4 DND Key

(Do Not Disturb) To block all audible signals from incoming calls.

### 5 HOLD Key & INTERCOM Lamp

a) To place calls on hold.

b) To indicate intercom status.

### 6 REDIAL Key

To automatically redial the last number dialled.

@DIRECT ACCESS Keys

These keys have two functions:

a) Direct Station Selection (DSS)

When the handset is lifted, or the station is in 'off-hook' mode, these keys are used to make intercom calls to other stations.

b) Speed Dial

When the handset is lifted or the station is in 'off-hook' mode, and the exchange line is also selected, these keys are used to select pre-programmed speed dial numbers.

### 8 DOOR Key

a) To monitor the door station or answer calls from the door station.

b) Call Transfer - Exchange calls

To control the Centel®/Easycall™ transfer function.

@PAGE Key

a) To establish an all station page.

b) Call Conference - Exchange Calls

To control the Centel/Easycall conference function.

@MEMORY Key

To program speed dial and abbreviated dial memory locations.

@RECALL Key

a) If your system is a PABX extension: to allow access to the host PABX facilities.

b) To control Easycall/Centel functions.

### 12 CONFERENCE Key

To establish multi station conferences on the exchange line.

@CALL BACK Key

To control the Centel/Easycall call back function.

### 14 CALL DIVERT Key

To control the Centel/Easycall call diversion functions.

### 15 CALL WAITING Key

To control the Centel/Easycall call waiting function.

## Visual Signals

LAMP	LAMP STATUS	MEANING
[LINE]	Off Steady glow Slow flash Medium flash Rapid flash	Line free Line busy Line on hold Line ringing Conference in progress
Intercom (located in the [HOLD] key)	Off Steady glow Slow flash	Intercom link free Intercom link busy Incoming intercom call
[DND]	Steady glow	Do Not Disturb activated
[SPKR]	Steady glow	On-hook dialling activated
[HSET/MODE]	Off Steady glow	Handset Mode off Headset Mode activated

## Audible Signals

SIGNAL	MEANING
Normal ring	Outside call
Continuous short ring	Intercom call
Short beep followed by voice	Intercom voice call
Two long beeps	All-station page
Double chime	Door Station call
Two short bursts of ring repeated at 90 seconds intervals	Hold recall

## Service Tone

TONE	MEANING
Continuous short tone	Intercom ring
Slow repeating tone	Busy
Long repeating tone	Error

## Access Barring

During installation each station will be allocated one of two modes of call barring:

- **Unrestricted mode**
- **Restricted mode**  
Numbers **dialled** are compared to an exception table. If a match is found the call is allowed.

This table consists of two areas:

A programmable area consisting of eight entries of four digits each, and;

A non-programmable area with fixed emergency numbers, etc.

## Centel Features

---

The Commander E105/208+ is compatible with Centel/Easycall facilities provided the system has been programmed to meet the following conditions:

- DTMF Dialling
- Stations must have Unrestricted access.

Subject to Centel connection the Commander E105/208+ has five preprogrammed keys which control the Centel/Easycall functions:

- Call Back
- Call Diversion
- Call Waiting
- Call Transfer
- Call Conference

Details of each function are covered in Section 6 - Centel Features.

For further information on operation and programming of Centel facilities refer to Centel/Easycall User Guide.

## **2. Answering Calls**

---

## Intercom Calls

---

### Ringling at Your Station

#### To Answer Intercom Calls Ringling at Your Station:

- Hear the intercom ring signal  
*The intercom lamp flashes slowly at your station.*
- Lift the handset.

### Ringling at Another Station

#### To Answer Intercom Calls Ringling at Another Station:

- Hear the intercom ring signal at another station  
*The intercom lamp glows steadily at your station.*
- Lift the handset at your station
- 

---

## Outside Calls

---

#### To Answer Outside Calls:

- Hear the normal ring signal
- Lift the handset
- Press the appropriate medium flashing [LINE].

During installation, stations can be programmed to have no audible signal, if required. However, calls can still be answered by pressing the appropriate [LINE].

---

#### If Automatic Exchange line Answer is Programmed:

- Hear the normal ring signal
- Lift the handset - the call is answered.

(If more than one call is ringling, the call ringling the longest is answered.)

If more than one call is ringling, a particular call may be answered first by pressing the [LINE] key and then lifting the handset.

---

## Door Station Calls

---

#### To Answer Calls From the Door Station:

- Hear the Door Station chime
- Lift the handset
- Press [DOOR].

*The intercom lamp glows steadily at all stations.*

A call from the Door Station cannot be answered from a station if the intercom link is already in use.

Door Station calls will only chime at stations programmed to receive paging.

### **3. Making Calls**

---

---

## Intercom Calls

---

### Intercom Signal Call

To Make an Intercom Call that will Ring at the Called Station:

- Ensure that the intercom lamp is extinguished
- Lift the handset
- Press required DSS key [1-8]

*The intercom **lamp** glows steadily at all other stations.*

- Hear the intercom ring tone
- Speak when called party answers.

If the called station is busy or in Do Not Disturb mode, you hear a busy tone.

### Intercom Voice Call

To Make an Intercom Call in which your Voice Sounds Through the Called Station's Speaker:

- Ensure that the intercom lamp is extinguished
- Lift the handset
- Press required DSS key [1-8]

*The intercom lamp glows steadily at all other stations.*

- Press DSS key again [1-8]
- Hear a short beep
- Page the called party.

---

## Outside Calls

---

### Off-hook Dialling

To Make an Outside Call with the Handset Off-hook:

- Lift the handset
- Press a free [LINE]

*The selected [LINE] lamp glows steadily at all stations.*

- Hear the dial tone
- Dial the required number
- Speak when the called party answers.

### On-hook Dialling

To Initiate an Outside Call Using the On-hook Facility:

- Press a free [LINE] without lifting the handset

*The [SPKR] lamp glows steadily at your station.  
The selected [LINE] lamp glows steadily at all stations.*

- Hear the dial tone through the station speaker
- Dial the required number
- Lift the handset to speak when the called party answers.

*The [SPKR] lamp extinguishes.*

To Cancel an Outside Call Made with the On-hook Facility if the Called Party is Busy or Does Not Answer:

- Press [SPKR].

*The [SPKR] lamp extinguishes.  
The selected [LINE] lamp extinguishes.*

## last Number Redial

To Initiate Automatic Redialling of the last Number **Dialled** with the Handset Off-hook:

- Lift the handset
- Press a free [LINE]  
*The selected [LINE] lamp glows steadily at all stations.*
- Hear the dial tone
- Press [REDIAL].  
*The last number dialled is automatically redialled.*

Last number redial calls can also be initiated using the on-hook facility.

## Speed Dialling

This facility allows each station to access eight speed dial numbers previously stored in that station.

For speed dial number storing procedures, see page 7-2

To Dial a Stored Number:

- Lift the handset
- Press a free [LINE]  
*The [LINE] lamp glows steadily at all stations.*
- Hear the dial tone
- Press required speed dial key [1-8].  
*The stored number is dialled automatically.*

You can also initiate speed dialling using the on-hook facility.

## Abbreviated Dialling

This facility allows each station to access two abbreviated dial numbers previously stored in that station.

For abbreviated dial number storing procedures, see page 7-3.

To Dial a Stored Number:

- Lift the handset
- Press a free [LINE]  
*The [LINE] lamp glows steadily at all stations.*
- Hear the dial tone
- Press [MEMORY]
- Press required abbreviated dial key [0 or 9].  
*The stored number is dialled automatically.*

You can also initiate abbreviated dialling using the on-hook facility.

---


## Door Station Calls

---

To Call the Door Station:

- Ensure that the intercom lamp is extinguished
- Lift the handset
- Press [DOOR].  
*The intercom lamp glows steadily at all stations.*

) ) )



## **4. Holding and Transferring Calls**

---

---

## Holding Calls

---

### To Place an Outside Call on Hold:

- Ask the outside party to wait
- Press [HOLD]

*The [LINE] lamp flashes slowly at all stations.  
The outside party hears music. (If programmed.)*

- The handset can be replaced.

### To Retrieve a Held Call from Any Station:

- Lift the handset
- Press the appropriate slowly flashing [LINE].

If a call on hold is not retrieved within 90 seconds, the hold recall signal rings. This signal will repeat at 90 second intervals until the call is retrieved.

### To Make an Inquiry Call while a Call is on Hold:

- Ask the outside party to wait
- Press [HOLD]  
*The [LINE] lamp flashes slowly at all stations.  
The outside party hears music.*
- Press required DSS key [1-8] or make an outside call on the other line if equipped
- Make your inquiry
- Press the appropriate slowly flashing [LINE] to return to the held call.

---

## Transferring Calls

---

Any outside call can be transferred to another station.

### To Transfer a Call:

- Ask the outside party to wait
- Press [HOLD]

*The [LINE] lamp flashes slowly at all stations.  
The outside party is placed on hold and hears music.*

- Ensure that the intercom lamp is extinguished
- Press the required DSS key [1-8]


*The intercom lamp glows steadily at all other stations.*

- Announce the transfer
- Replace the handset.

*The call is answered at the called station by pressing the appropriate slowly flashing [LINE].*

)

)



## **5. Paging and Conference Calls**

---

---

## Paging

---

Announcements can be made through the speakers of all idle stations in the pre-programmed paging zone.

### All-Station Page

To Make a General Announcement to all Stations in the Paging Zone:

- Ensure that the intercom lamp is extinguished
- Lift the handset
- Press [PAGE]

*The intercom lamp glows steadily at all stations.  
Two beeps are heard through the speakers **of** all idle and page included stations.*

- Make the announcement
- Replace the handset.

---

## Meet-Me Page

To Request a Specific Person to Contact the Originator of a Page Immediately After an Announcement:

- Ensure that the intercom lamp is extinguished
- Lift the handset
- Press [PAGE]

*The intercom lamp glows steadily at all stations.  
Two beeps are heard through the speakers **of** all idle stations.*

- Make an announcement, requesting that the person contact you
- Leave the handset off-hook.

*The paged person presses [PAGE] to automatically connect to your station.*

---

## Conference Calls

---

Conference calls can be conducted between an outside party and two stations, or between three stations.

### Conference with an Outside Party

#### To Set Up a Conference Call with an Outside Party:

- Ask the outside party to wait
- Press [CONF]
- Press required DSS key [1-8]

*The [LINE] lamp flashes slowly.*

*The intercom lamp glows steadily at all other stations.*

*The outside party is placed on hold and hears music. (If programmed.)*

- Ask the new party to wait
- Press [CONF].

*The [LINE] lamp flashes rapidly.*

*All parties are connected to the conference call.*

*The intercom lamp extinguishes.*

If the person at the station is busy, does not answer or does not wish to join the conference, you can return to the outside party by pressing the flashing [LINE].

Press [CONFERENCE] again and press another DSS key to try another station.

If one of the stations leaves the conference, the [LINE] lamp will change to a steady glow.

---

## Intercom Conference

### To Set Up an Intercom Conference Call:

- Ensure that the intercom lamp is extinguished
- Lift the handset
- Press required DSS key [1-8]

*The intercom lamp glows steadily at all other stations.*

- Ask the party to wait
- Press [CONF]
- Press the second DSS key [1-8].

*When the call is answered, the conference call is automatically connected.*

## **6. Centel Features**

---

## Call Back

---

Refer to Centel User Guide for a complete description of this feature.

### To Set Call Back:

- Lift the handset
- Press a free [LINE]  
*The selected [LINE] lamp glows steadily at all stations.*
- Hear the dial tone
- Dial the required number or press the appropriate speed dial key [1-8]
- If you hear busy tone press [CALL BACK]  
*The dial sequence \*37# is automatically sent to line.*
- Replace the handset.

### To Cancel Call Back:

- Lift the handset
- Press a free [LINE]  
*The selected [LINE] lamp glows steadily at all stations.*
- Press [CALL BACK]  
*The dial sequence #37# is automatically sent to line.*
- Replace the handset.

The E105/208+ will not ring with the distinctive Centel call back cadence. Call back calls are presented as normal calls.

---

## Call Diversion

---

Refer to Centel User Guide for a complete description of this feature.

### Call Diversion - Immediate

#### To Store Call Diversion - Immediate:

- Press [CALL DIVERT]
- Press [1]
- Lift and replace the handset.

The divert immediate code is now stored under the [CALL DIVERT] key.

#### To Set Call Diversion - Immediate:

- Lift the handset
- Press a free [LINE]  
*The selected [LINE] lamp glows steadily at all stations.*
- Press [CALL DIVERT]
- Dial number to which calls are to be diverted or press speed dial key  
*The dial sequence \*21 is sent to line automatically before the telephone number:*
- Press [CALL DIVERT]  
*The dial sequence # is sent to line.*
- Replace the handset.

**To Clear Call Diversion - Immediate:**

- Lift the handset
- Press a free [LINE]

*The selected [LINE] lamp glows steadily at all stations.*

- Press [CALL DIVERT] twice

*The dial sequence #21# is sent to line.*

- Replace the handset.

**Call Diversion - Busy****To Store Call Diversion - Busy:**

- Press [CALL DIVERT]
- Press [2]
- Lift and replace the handset.

The divert on busy code is now stored under the [CALL DIVERT] key.

**To Set Call Diversion - Busy:**

- Lift the handset
  - Press a free [LINE]
- The selected [LINE] lamp glows steadily at all stations.*
- Press [CALL DIVERT]
  - Dial number to which calls are to be diverted or speed dial key

*The dial sequence \*24 is sent to line automatically before the telephone number:*

- Press [CALL DIVERT]

*The dial sequence # is sent to line.*

- Replace the handset.

**To Clear Call Diversion - Busy:**

- Lift the handset
- Press a free [LINE]

*The selected [LINE] lamp glows steadily at all stations.*

- Press [CALL DIVERT] twice

*The dial sequence #24# is sent to line.*

- Replace the handset.

**Call Diversion - No Answer****To Store Call Diversion - No Answer:**

- Press [CALL DIVERT]
- *Press* [3]
- Lift and replace the handset.

The divert on no answer code is now stored under the [CALL DIVERT] key.

### To Set Call Diversion - No Answer:

- Lift the handset
- Press a free [LINE]  
*The selected [LINE] lamp glows steadily at all stations.*
- Press [CALL DIVERT]
- Dial number to which calls are to be diverted or speed dial key  
*The dial sequence \*61 is sent to line automatically before the telephone number*
- Press [CALL DIVERT]  
*The dial sequence # is sent to line.*
- Replace the handset.

### To Clear Call Diversion - No Answer:

- Lift the handset
- Press a free [LINE]  
*The selected [LINE] lamp glows steadily at all stations.*
- Press [CALL DIVERT] twice  
*The dial sequence #61# is sent to line.*
- Replace the handset.

## Call Waiting

Refer to Centel User Guide for a complete description of this feature.

### To Hold the Original Call and Answer the Waiting Call:

- Press [CALL WAIT].  
*The dial sequence 'recall 2' is sent to line.*

The original call is placed on hold and the waiting call is answered.

### To Return to the Original Call:

- Press [CALL WAIT].  
*The dial sequence 'recall 2' is sent to line.*

The second call is placed on hold and the original call is reconnected.

### To Alternate Between Calls:

- Press [CALL WAIT].  
*The dial sequence 'recall 2' is sent to line.*

This process can be repeated indefinitely to alternate between the two calls as required.

### To Release Current Call and Reconnect the Waiting Call:

- Press [RECALL]
- Press [I]

The current call is released and the waiting call reconnected.

---

## Call Transfer

---

Refer to Centel User Guide for a complete description of this feature.

### To Transfer Exchange Call:

- Press [RECALL]
- Dial number to which the call is to be transferred
- Speak to the called party
- Press [DOOR]

*The dial sequence 'recall 4' is sent to line.*

- Replace the handset.

### To Cancel Exchange Call Transfer if Called Party Does Not Answer:

- Press [RECALL]
- Press [1].

The call transfer feature may only be used in conjunction with other system call handling functions, on stations programmed as 'unrestricted'. If used in conjunction with other call handling functions on restricted stations, the access barring system will not allow dialling to the transfer number.

---

## Call Conference

---

Refer to Centel User Guide for a complete description of this feature.

### To Establish Conference Call While on an Exchange Call:

- Press [RECALL]
- Dial the second number which is to be included in the conference call, or press speed dial
- Press [PAGE].

*The dial sequence 'recall 3' is sent to line.*

Conversation is now possible between all three parties.

The call conference feature may only be used in conjunction with other system call handling functions, on stations programmed as 'unrestricted'. If used in conjunction with other call handling functions on restricted stations, the access barring system will not allow dialling to the wanted conference number.



---

## Storing Speed Dial Numbers

---

You can programme and store up to eight speed dial numbers in each station which can be used only at that station. You can access each of these numbers by pressing the appropriate speed dial key.

For speed dialling procedures, see page 3-4.

### To Store a Speed Dial Number in a Station's Memory:

- Lift the handset
- Press [MEMORY]
- Press a speed dial key [1-8]
- Dial the telephone number to be stored.

A maximum of 19 digits can be programmed for each telephone number. It is not possible to store [RECALL] as part of a speed dial number.

If a station has been designated as a PABX extension, a three-second pause is automatically inserted after the first digit. The pause can also be inserted in a speed dial number by pressing [REDIAL] while storing the number.

### To Add Further Speed Dial Numbers:

- Press [MEMORY] again
- Press another speed dial key [1-8]
- Dial the next telephone number to be stored
- Continue this sequential procedure until you have stored all required numbers.

When you have finished entering numbers:

- Replace the handset.

---

## Storing Abbreviated Dial Numbers

---

You can programme and store two abbreviated dial numbers in each station which can be used only at that station. You can access these two numbers by dialling the appropriate one-digit memory code.

For abbreviated dialling procedures, see page 3-5.

### To Store an Abbreviated Dial Number in a Station's Memory:

- Lift the handset
- Press [MEMORY]
- Press dial key [0] or [9]
- Dial the telephone number to be stored.

A maximum of 19 digits can be programmed for each telephone number. It is not possible to store [RECALL] as part of an abbreviated number.

If a station has been designated as a PABX extension, a three-second pause is automatically inserted after the first digit. The pause can also be inserted in an abbreviated dial number by pressing [REDIAL] while storing the number.

---

## Confidence Tone

---

You can programme your station to emit a low-level tone indicating when a key has been pressed.

### To Activate or Cancel the Confidence Tone:

- Press [\*] without lifting the handset.

---

## Decadic to Tone Signalling

---

If your system is programmed for decadic signalling, you can change to tone signalling to access services such as telephone banking and personal remote paging.

### To Activate Tone Signalling:

- Access the desired service
- Press [HSET/MODE] to change from decadic to tone signalling
- Dial the numbers required by the service
- Complete your transaction
- Replace the handset.

*Decadic signalling automatically resumes on the next call.*

---

## Background Music

---

If your system has access to music from an external source, this music can be played through your station speaker when your station is idle.

### To Activate the Background Music:

- Press [#] twice within one second without lifting the handset.

### To Cancel the Background Music:

- Press [#] once without lifting the handset.

Background music is temporarily disabled if the handset is lifted, a call is received, or any station uses the intercom link.

---

## Do Not Disturb

---

This facility allows you to programme your station to block all audible signals from incoming calls.

### To Activate Do Not Disturb:

- Press [DND] without lifting the handset.

*The [DND] lamp glows steadily at your station.*

*All audible signals from incoming calls are blocked at your station.*

*Stations trying to call your station hear a busy tone.*

Outside calls can still be answered in the normal manner while Do Not Disturb is activated.

### To Cancel Do Not Disturb:

- Press [DND] without lifting the handset.

*The [DND] lamp extinguishes.*

*Audible signals from incoming calls will be heard at your station.*

---

## PABX Recall

---

If your system is an extension of a PABX, you can transfer calls to other stations on the PABX, or access other PABX facilities.

### To Contact the Host PABX while Connected to a line:

- Press [RECALL]
- Hear the PABX dial tone
- Follow the instructions in your PABX User Guide.

## Headset Mode

---

A keystation handset may be replaced by a suitable Austel permitted headset. When connected and activated, the [SPKR] key is used to perform the off-hook function. Headset mode is protected against accidental activation and de-activation by a two-key activation sequence.

### **To Activate Headset Mode:**

With the handset on-hook:

- Press and hold [HSET/MODE]
- Press and release [SPKR].

### **To De-Activate Headset Mode**

With the handset on-hook:

- Press and hold [HSET/MODE]
- Press and release [SPKR].

### **To Select Headset Mode Once Activated:**

- Press [HSET/MODE].

*The [HSET/MODE] key will glow.*

### **To De-Select Headset Mode Once Activated:**

- Press [ HSET/MODE].

*The [HSET/MODE] key will go out.*

When Headset mode is selected, the handset function is controlled by pressing the [SPKR] key.

When in Headset mode the station cannot be operated in off-hook mode.

## **8 General Information**

---

## Care of Your Commander

---

Commander telephone systems are manufactured to meet the highest quality standards.

Follow these common-sense guidelines to help maintain trouble-free service:

- Handle your keystation with care. Avoid dropping or knocking it.
- Avoid subjecting the equipment to temperature extremes or damp, steamy or greasy conditions.
- Never immerse the equipment in water. Clean the surface with a slightly damp cloth. Do not use detergents, polishes or commercial cleaners.
- Do not tamper with your Commander in any way. Interference with its sensitive electrical components could render it unsafe to use.

---

## Service Problems

---

### Power Failure

To prevent loss of service during power failure, an optional facility is available which will automatically connect the first outside line to a specially provided single-line telephone.

If this special telephone is not provided, calls cannot be received or made under power failure conditions.

In the event of a power failure, the system will retain all programmed data for a minimum of 24 hours.

---

## Other Difficulties

If operating difficulties occur, first determine if power is available. If difficulties persist, and your equipment is covered by a Telstra Maintenance Agreement, call Service Difficulties (13 2999).

---

## System Enhancement

---

If you require additional key stations or a larger system, please contact your local Telstra Representative or call the nearest Telstra Business Office listed in the information pages of the telephone directory.