



# SP92 USB Speakerphone Quick Start Guide



English / 简体中文

## **Package Contents**








- (1) SP92
- (4) USB C/A Adapter

- 2 Zipper Bag
- (5) USB 2.0 Cable (USB-C to USB-C)

- 3 BT51C (optional)
- 6 Quick Start Guide


Yealink provides a USB device manager client - Yealink USB Connect, you can download it on the Yealink website support.yealink.com.

## **How to Connect**




## **How to Place**

Small/Medium meeting room




### **How to Use**



- 7 Hold 3 seconds to power on/off.
- 3 5 Tap to control calls.
- 8 Hold 2 seconds to enter the pairing mode, search and connect on the smartphone.
  Double-tap to disconnect. Tap again to reconnect.
- (2)(4) Tap to turn up/down volume.
- (Teams Edition) Tap to invoke the Teams client; Hold 2 seconds to activate Cortana. (UC Edition) Hold 2 seconds to activate smartphone's voice assistant.

## 包装清单





① SP92

(2) 便携包

③BT51C(可选)


- ④ USB C/A 转接头
- ⑤ USB 充电线

⑤ 快速入门指南


<sup>☑</sup> 亿联提供 Yealink USB Connect 升级管理工具,请从 support.yealink.com 下载。

## 连接


USB 连接和充电



## 摆放位置



## 使用



- ⑦ 长按3秒开机/关机。
- 3 5 按下按键控制通话。
- ⑧ 长按2秒进入蓝牙配对模式,然后在智能手机搜索和连接。 双击断开连接。再次按下按键可重新连接。
- (2)(4) 按下按键调高或调低音量。
- ①(Teams 版本)按下按键调出 Teams 客户端;长按 2 秒激活 Cortana。 (UC 版本)长按 2 秒唤醒智能手机的语言助手。

EU Regulatory Information Support Frequency Bands and Power: DECT 1.8GHz-1.9GHz< 24 dBm Bluetooth 2.4 GHz < 20 dBm; WLAN 2.4 GHz < 20 dBm; WLAN 5150-5250 MHz < 23 dBm; WLAN 5250-5350 MHz < 20 dBm; WLAN 5470-5725 MHz < 27 dBm; WLAN 5745-5825 MHz < 14 dBm;

#### Regulatory Notices


#### Operating Ambient Temperatures

- Operating temperature: +32 to 104°E (0 to 40°C). Belative humidity: 5% to 90%, noncondensing.
- Storage temperature: -22 to +160°F (-30 to +70°C).

Our product warranty is limited only to the unit itself, when used normally in accordance with the operation instructions and the system environment. We are not liable for damage or loss resulting from the use of this product, or for any claim from a third party. We are not liable for problems with Yealink device arising from the use of this product; we are not liable for financial damages, lost profits, claims from third parties, etc., arising from the use of this product.

#### Explanation of the symbols

- DC symbol
- is the DC voltage symbol. WFFF Warning symbol
- To avoid the potential effects on the environment and human health as a result of the presence of hazardous



#### waste and have to collect such WEEE separately Restriction of Hazardous Substances Directive (RoHS)

This device complies with the requirements of the EU RoHS Directive. Statements of compliance can be obtained by contacting support@yealink.com.

#### Safety Instructions

Save these instructions. Read these safety instructions before use!

#### A General Requirements

- . Before you install and use the device, read the safety instructions carefully and observe the situation during opera-
- During the process of storage transportation and operation please always keep the device dry and clean applicacollision and crash
- Please attempt not to dismantie the device by yourself. In case of any discrepancy, please contact the appointed maintenance center for repair.
- . Please refer to the relevant laws and statutes while using the device, Legal rights of others should be respected as

#### ♠ Environmental Requirements

- Place the device at a well-ventilated place. Do not expose the device under direct surficitit.
- . Keen the device dry and free of dusts • Do not place the device on or near any inflammable or fire-vulnerable object, such as rubber-made materials. . Keep the device away from any heat source or bare fire, such as a candle or an electric heater.

#### ⚠ Operating Requirements

- . Do not let a child operate the device without guidance.
- Do not let a child play with the device or any accessory in case of accidental swallowing. Please use the accessories provided or authorized by the manufacturer only.
- . The power supply of the device shall meet the requirements of the input voltage of the device. Please use the provided surge protection power socket only
- Before plugging or unplugging any cable, make sure that your hands are completely dry. . Do not spill liquid of any kind on the product or use the equipment near water, for example, near a bathfulb wash-
- bowl, kitchen sink, wet basement or near a swimming pool. . During a thunderstorm, stop using the device and disconnect it from the power supply. Unplug the power plug and
- the Asymmetric Digital Subscriber Line (ADSL) twisted pair (the radio frequency cable) to avoid lightning strike. . If the device is left unused for a rather long time, disconnect it from the power supply and unplug the power plug.
- . When there is smoke emitted from the device, or some abnormal noise or smell, disconnect the device from the power supply, and unplug the power plug immediately.
- Contact the specified maintenance center for repair. . Do not insert any object into equipment slots that is not part of the product or auxiliary product.
- . Before connecting a cable, connect the grounding cable of the device first. Do not disconnect the grounding cable until you disconnect all other cables.

### A Battery Requirements

- . Do not immerse the battery into water, which could short-circuit and damage the battery . Do not expose the battery to an open flame or leave the battery where it could be subjected to extremely high
- temperatures, which could cause the battery to explode. . Do nower the handret off before removing the battery
- . Do not try to use the battery for the power supply of any device other than this bandset
- Do not onen or muliate the hattery released electrolide is corrosive and may cause damage to your eyes or skin.
- Use only the rechargeable battery pack delivered with the handset or those rechargeable battery packs expressly recommended by Yealink . Defective or exhausted battery should never be disposed of as municipal waste. Return old battery to the battery supplier, a licensed battery dealer or a designated collection facility

#### Cleaning Requirements

. Before cleaning the device, disconnect it from the power supply. Use a piece of soft, dry and anti-static cloth to clean the device.

#### . Keen the nower plug clean and dry Troubleshooting

#### The unit cannot supply power to Yealink device.

There is a had connection with the nlug 1. Clean the plug with a dry cloth

2. Connect it to another wall outlet

The usage environment is out of operating temperature range. 1. Use in the operating temperature range

The cable between the unit and the Yealink device is connected incorrectly. 1. Connect the cable correctly

- You cannot connect the cable properly
- 1. You may have connected a wrong Yealink device. 2. Use the correct power supply
- Some dust, etc., may be in the port.
- 1. Clean the port. Contact your dealer or authorized service facility for any further questions

#### FCC Statement

This device complies with part 15 of the ECC Bules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's

authority to operate the equipment

#### IC Statement This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

(1) this device may not cause interference; and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) l'appareil ne doit pas produire de brouillage: (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement NMB-3(B)

#### Radiation Exposure Statement

This equipment complies with FCC and IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Cet émetteur ne doit pas être Co-placé ou ne fonctionnant en même temps qu'aucune autre antenne ou émetteur. Cet équipement devrait être installé et actionné avec une distance minimum de 20 centimètres entre la radiateur et votre corps.

#### Contact Information

YEALINK NETWORK TECHNOLOGY CO. LTD.

309, 3rd Floor, No.16, Yun Ding North Road, Huli District, Xiamen City, Fujian, P.R.C. YEALINK (EUROPE) NETWORK TECHNOLOGY B.V. Strawinskylaan 3127, Atrium Building, 8th floor, 1077ZX Amsterdam, The Netherlands

YEALINK (USA) NETWORK TECHNOLOGY CO., LTD. 999 Peachtree Street Suite 2300 Fulton Atlanta GA 30309 USA

Made in China